USER'S GUIDE



DCP-385C
DCP-383C
DCP-387C
DCP-585CW

Version 0

UK/IRE/GEN/SAF

Downloaded from ManualsPrinter.com Manuals

If you need to call Customer Service

Please complete the following information for future reference:

Model Number: DCP-385C, DCP-383C, DCP-387C and DCP-585CW (Circle your model number)

Serial Number: [1] _____

Date of Purchase: _____

Place of Purchase: _____

[1] The serial number is on the back of the unit. Retain this User's Guide with your sales receipt as a permanent record of your purchase, in the event of theft, fire or warranty service.

Register your product on-line at

http://www.brother.com/registration/

By registering your product with Brother, you will be recorded as the original owner of the product. Your registration with Brother:

- may serve as confirmation of the purchase date of your product should you lose your receipt; and
- may support an insurance claim by you in the event of product loss covered by insurance.

© 2008 Brother Industries, Ltd.

Downloaded from ManualsPrinter.com Manuals

Compilation and Publication Notice

Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product descriptions and specifications.

The contents of this manual and the specifications of this product are subject to change without notice.

Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

Downloaded from ManualsPrinter.com Manuals

EC Declaration of Conformity under the R & TTE Directive

EC Declaration of Conformity

Manufacturer
Brother Industries, Ltd.
15-1, Naeshiro-cho, Mizuho-ku, Nagoya 467-8561, Japan
Plant
Brother Industries (Shen Zhen) Ltd
G02414-1, Bao Chang Li Bonded Transportation Industrial Park,
Bao Long Industrial Estate, Longgang, Shenzhen, China

Herewith declare that:
Products description : **Copier Printer**
Model Name : **DCP-385C, DCP-383C, DCP-387C**
are in conformity with provisions of the Directives applied : Low Voltage Directive 2006/95/EC and the Electromagnetic Compatibility Directive 2004/108/EC.

Products description : **Copier Printer**
Model Number : **DCP-585CW**
is in conformity with provisions of the R & TTE Directive (1999/5EC) and we declare compliance with the following standards :
Standards applied :

Harmonized : Safety: EN60950-1:2001+ A11:2004

EMC: EN55022: 2006 Class B
EN55024: 1998+ A1: 2001+ A2: 2003
EN61000-3-2: 2006
EN61000-3-3: 1995+ A1: 2001+ A2:2005

Radio EN301 489-1 V1.6.1
EN301 489-17 V1.2.1
EN300 328 V1.7.1

※ Radio applies to DCP-585CW only.

Year in which CE marking was First affixed : 2008

Issued by : Brother Industries, Ltd.

Date : 7th March, 2008

Place : Nagoya, Japan

Signature :

Junji Shiota
General Manager
Quality Management Dept.
Printing & Solutions Company

Downloaded from ManualsPrinter.com Manuals

Table of Contents

Section I General

1 General Information 2

Using the documentation 2
Symbols and conventions used in the documentation 2
Accessing the Software User's Guide and Network User's Guide 2
Viewing Documentation 2
Accessing Brother Support (For Windows®) 5
Control panel overview 6
LCD display indications 7
Basic Operations 7
Warning LED indications 8

2 Loading documents and paper 9

Loading paper and other print media 9
Loading envelopes and post cards 11
Loading photo paper 13
Removing small printouts from the machine 14
Printable area 15
Acceptable paper and other print media 16
Recommended print media 16
Handling and using print media 16
Choosing the right print media 18
Loading documents 20
Using the scanner glass 20
Scannable area 20

3 General setup 21

Paper settings 21
Paper Type 21
Paper Size 21
Sleep Mode 22
LCD display 22
Changing LCD language 22
LCD Contrast 22
Setting the backlight brightness 23
Setting the Dim Timer for the backlight 23
Printing Reports 23
How to print a report 23

Downloaded from ManualsPrinter.com Manuals

Section II Copy

4 Making copies 26

How to copy 26
Making a single copy 26
Making multiple copies 26
Stop copying 26
Copy options 26
Changing copy speed and quality 27
Enlarging or reducing the image copied 27
Making N in 1 copies or a poster (Page Layout) 28
Adjusting Brightness and Contrast 29
Paper options 30
Book Copy 30
Watermark Copy 31
Setting your changes as a new default 32
Restoring all settings to the factory settings 32

Section III Direct Photo Printing

5 Printing photos from a memory card or USB Flash memory drive 34

PhotoCapture Center™ Operations 34
Printing from a memory card or USB Flash memory drive without a PC 34
Scanning to a memory card or USB Flash memory drive without a PC 34
Using PhotoCapture Center™ from your computer 34
Using a memory card or USB Flash memory drive 34
Memory cards or a USB Flash memory drive folder structure 35
Getting started 36
Entering PhotoCapture mode 37
Print Images 37
View Photo(s) 37
Print Index (Thumbnails) 38
Printing Photos 38
Enhance Photos 39
Search by Date 42
Print All Photos 43
Slide show 43
Trimming 44
DPOF printing 44

Downloaded from ManualsPrinter.com Manuals

PhotoCapture Center™ print settings 45
Print Speed and Quality 46
Paper options 46
Adjusting Brightness, Contrast and Colour 47
Cropping 48
Borderless printing 48
Date Print 48
Setting your changes as a new default 49
Restoring all settings to the factory settings 49
Scan to a memory card or USB Flash memory drive 49
Entering Scan mode 49
How to scan to a memory card or USB Flash memory drive 50
How to set new default 51
How to reset to factory settings 51
Understanding the Error Messages 51

6 Printing photos from a camera 52

Printing photos directly from a PictBridge camera 52
PictBridge requirements 52
Setting your digital camera 52
Printing Images 53
DPOF printing 53
Printing photos directly from a digital camera (without PictBridge) 53
Printing Images 54
Understanding the Error Messages 54

Section IV Software

7 Software and Network features 56

Section V Appendixes

A Safety and Legal 58

Choosing a location 58
To use the machine safely 59
Important safety instructions 62
IMPORTANT - For your safety 63
LAN connection (DCP-585CW only) 63
Radio interference 63
EU Directive 2002/96/EC and EN50419 64
International ENERGY STAR® Compliance Statement 64
Legal limitations for copying 65
Trademarks 66

Downloaded from ManualsPrinter.com Manuals

B Troubleshooting and Routine Maintenance 67

Troubleshooting 67
If you are having difficulty with your machine 67
Error and Maintenance messages 72
Error animation 75
Printer jam or paper jam 75
Routine maintenance 77
Replacing the ink cartridges 77
Cleaning the outside of the machine 80
Cleaning the scanner glass 80
Cleaning the machine printer platen 81
Cleaning the paper pick-up roller 81
Cleaning the print head 82
Checking the print quality 82
Checking the print alignment 83
Checking the ink volume 84
Machine Information 84
Checking the serial number 84
Packing and shipping the machine 84

C Menu and Features 87

On-screen programming 87
Menu table 87
Mode and menu keys 87
Menu table 88

D Specifications 101

General 101
Print media 103
Copy 104
PhotoCapture Center™ 105
PictBridge 106
Scanner 107
Printer 108
Interfaces 109
Computer requirements 110
Consumable items 111
Network (LAN) (DCP-585CW only) 112
Wireless one-push configuration 113

E Glossary 114

F Index 115

Downloaded from ManualsPrinter.com Manuals

Section I

General

General Information 2
Loading documents and paper 9
General setup 21

Downloaded from ManualsPrinter.com Manuals

1 General Information

Using the documentation

Thank you for buying a Brother machine! Reading the documentation will help you make the most of your machine.

Symbols and conventions used in the documentation

The following symbols and conventions are used throughout the documentation.

Bold	Bold typeface identifies specific button on the machine's control panel, on the computer screen.
Italics	Italicized typeface emphasizes an important point or refers you to a related topic.
`Courier New`	Text in Courier New font identifies messages on the LCD of the machine.

Warnings tell you what to do to prevent possible personal injury.

Cautions specify procedures you must follow or avoid to prevent possible damage to the machine or other objects.

Electrical Hazard icons alert you to possible electrical shock.

Notes tell you how you should respond to a situation that may arise or give tips about how the operation works with other features.

Improper Setup icons alert you to devices and operations that are not compatible with the machine.

Accessing the Software User's Guide and Network User's Guide

This User's Guide does not contain all the information about the machine such as how to use the advanced features of Printer, Scanner and Network (DCP-585CW only). When you are ready to learn detailed information about these operations, read the **Software User's Guide** and **Network User's Guide**.

Viewing Documentation

Viewing Documentation (For Windows®)

To view the documentation, from the **Start** menu, point to **Brother**, **DCP-XXXX** (where XXXX is your model name) from the programs group, and then choose **User's Guides in HTML format**.

If you have not installed the software, you can find the documentation by following the instructions below:

1. Turn on your PC. Insert the Brother CD-ROM into your CD-ROM drive.
2. If the model name screen appears, click your model name.

Downloaded from ManualsPrinter.com Manuals

3 If the language screen appears, click your language. The CD-ROM Main Menu will appear.

Note

If this window does not appear, use Windows® Explorer to run the start.exe program from the root directory of the Brother CD-ROM.

4 Click **Documentation**.

5 Click the documentation you want to read.

- **HTML documents**: **Software User's Guide** and **Network User's Guide** in HTML format.

  This format is recommended for viewing on your computer.

- **PDF documents**: **User's Guide** for stand-alone operations, **Software User's Guide** and **Network User's Guide** in PDF format.

  This format is recommended for printing the manuals. Click to go to the Brother Solutions Center, where you can view or download the PDF documents. (Internet access and PDF Reader software are required.)

How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

Software User's Guide

- *Scanning*
  (For Windows® 2000 Professional/Windows® XP and Windows Vista®)
- *ControlCenter3*
  (For Windows® 2000 Professional/Windows® XP and Windows Vista®)
- *Network Scanning*
  (DCP-585CW only)

ScanSoft™ PaperPort™ 11SE with OCR How-to-Guides

- The complete ScanSoft™ PaperPort™ 11SE with OCR How-to-Guides can be viewed from the Help selection in the ScanSoft™ PaperPort™ 11SE application.

How to find Network setup instructions (DCP-585CW only)

Your machine can be connected to a wireless or wired network. You can find basic setup instructions in the Quick Setup Guide. If your wireless access point supports SecureEasySetup™, Wi-Fi Protected Setup™ or AOSS™, follow the steps in the Quick Setup Guide. For more information about network setup please see the Network User's Guide.

Downloaded from ManualsPrinter.com Manuals

Viewing Documentation (For Macintosh®)

1. Turn on your Macintosh®. Insert the Brother CD-ROM into your CD-ROM drive. The following window will appear.



2. Double-click the **Documentation** icon.
3. Double-click your language folder.
4. Double-click top.html to view the **Software User's Guide** and **Network User's Guide** in HTML format.



5. Click the documentation you want to read.
   - **Software User's Guide**
   - **Network User's Guide** (DCP-585CW only)

How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

Software User's Guide

- *Scanning* (For Mac OS® X 10.2.4 or greater)
- *ControlCenter2* (For Mac OS® X 10.2.4 or greater)
- *Network Scanning* (For Mac OS® X 10.2.4 or greater)
  (DCP-585CW only)

Presto!® PageManager® User's Guide

- The complete Presto!® PageManager® User's Guide can be viewed from the Help selection in the Presto!® PageManager® application.

How to find Network setup instructions (DCP-585CW only)

Your machine can be connected to a wireless or wired network. You can find basic setup instructions in the Quick Setup Guide. If your wireless access point supports SecureEasySetup™, Wi-Fi Protected Setup™ or AOSS™, follow the steps in the Quick Setup Guide. For more information about network setup please see the Network User's Guide.

Downloaded from ManualsPrinter.com Manuals

Accessing Brother Support (For Windows®)

You can find all the contacts you will need, such as Web support (Brother Solutions Center).

- Click **Brother Support** on the Main Menu. The following screen will appear:

- To access our web site (http://www.brother.com), click **Brother Home Page**.
- For the latest news and product support information (http://solutions.brother.com), click **Brother Solutions Center**.
- To visit our web site for original Brother Supplies (http://www.brother.com/original/), click **Supplies Information**.
- To access the Brother CreativeCenter (http://www.brother.com/creativecenter/) for FREE photo projects and printable downloads, click **Brother Creative Center**.
- To return to the main page, click **Back** or if you have finished, click **Exit**.

Downloaded from ManualsPrinter.com Manuals

Control panel overview

The **DCP-385C**, **DCP-383C**, **DCP-387C** and **DCP-585CW** have the same control panel keys.



1 LCD (liquid crystal display)

Displays messages on the screen to help you set up and use your machine.

Also, you can adjust the angle of the LCD screen by lifting it.

2 Number of Copies

Use this key to make multiple copies.

3 Menu keys:

- ◄ or ►

  Press to scroll backward or forward to a menu selection.

  Also, press to choose options.

- ▲ or ▼

  Press to scroll through the menus and options.

- **Clear/Back**

  Press to go back to the previous menu level.

- **Menu**

  Lets you access the main menu to program the machine.

- **OK**

  Lets you choose a setting.

4 Start keys:

- **Colour Start**

  Lets you start making copies in full colour. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

- **Mono Start**

  Lets you start making copies in monochrome. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

5 Stop/Exit

Stops an operation or exits from a menu.

6 On/Off

You can turn the machine on and off.

If you turn the machine off, it will still periodically clean the print head to maintain print quality. To maintain print quality, prolong print head life, and provide the best ink cartridge economy, you should keep your machine connected to the power at all times.

Downloaded from ManualsPrinter.com Manuals

7 Ink Management

Lets you clean the print head, check the print quality, and check the available ink volume.

8 Mode keys:

■ **Scan**

Lets you access Scan mode.

■ **Photo Capture**

Lets you access PhotoCapture Center™ mode.

9 Warning LED

Turns orange and blinks when the LCD displays an error or an important status message.

Note

Most of the illustrations in this User's Guide show the DCP-385C.

LCD display indications

The LCD display screen shows the mode the machine is in, the current settings, and the available ink volume.



1 Wireless Status (DCP-585CW only)

A four level indicator shows the current wireless signal strength if you are using a wireless connection.

0 Max

2 Ink indicator

Lets you see the available ink volume.

Basic Operations

The following steps show how to change a setting in the machine. In this example the Paper Type setting is changed from `Plain Paper` to `Inkjet Paper`.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.



Press **OK**.

3. Press ▲ or ▼ to choose `Paper Type`.
4. Press ◄ or ► to choose `Inkjet Paper`.
Press **OK**.
You can see the current setting on the LCD:



5. Press **Stop/Exit**.

Downloaded from ManualsPrinter.com Manuals

Warning LED indications

The Warning LED (light emitting diode) is a light that shows the status of the machine, as shown in the table.



LED	DCP status	Description
Off	Ready	The DCP is ready for use.
Orange	Cover open	The cover is open. Close the cover. (See *Error and Maintenance messages* on page 72.)
	Cannot Print	Replace the ink cartridge with a new one. (See *Replacing the ink cartridges* on page 77.)
	Paper error	Put paper in the tray or clear the paper jam. Check the LCD message. (See *Error and Maintenance messages* on page 72.)
	Other messages	Check the LCD message. (See *Error and Maintenance messages* on page 72.)

Downloaded from ManualsPrinter.com Manuals

2 Loading documents and paper

Loading paper and other print media

Note

To print on 10 x 15 cm or Photo L paper, you must use the photo paper tray. (See *Loading photo paper* on page 13.)

1. If the paper support flap is open, close it, and then close the paper support. Pull the paper tray completely out of the machine.



2. Lift the paper tray cover (1).



3. With both hands, gently press and slide the paper side guides (1) and then the paper length guide (2) to fit the paper size. Make sure that the triangular marks (3) on the paper side guides (1) and paper length guide (2) line up with the mark for the paper size you are using.



Note

When you use Legal size paper, press and hold the universal guide release button (1) as you slide out the front of the paper tray.



Downloaded from ManualsPrinter.com Manuals

4 Fan the stack of paper well to avoid paper jams and misfeeds.



Note

Always make sure that the paper is not curled.

5 Gently put the paper into the paper tray print side down and top edge in first. Check that the paper is flat in the tray.



6 Gently adjust the paper side guides (1) to the paper with both hands.
Make sure the paper side guides touch the sides of the paper.



Note

Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.

7 Close the paper tray cover.



Downloaded from ManualsPrinter.com Manuals

8 *Slowly* push the paper tray completely into the machine.



9 While holding the paper tray in place, pull out the paper support (1) until it clicks, and then unfold the paper support flap (2).



Note

Do not use the paper support flap for Legal paper.

Loading envelopes and post cards

About envelopes

- Use envelopes that weigh between 80 to 95 g/m^2.
- Some envelopes need margin settings to be set in the application. Make sure you do a test print first before printing many envelopes.

CAUTION

DO NOT use any of the following types of envelopes, as they will cause paper feed problems:

- That are of a baggy construction.
- That are embossed (have raised writing on them).
- That have clasps or staples.
- That are pre-printed on the inside.

Glue	Double flap
	

Occasionally you may experience paper feed problems caused by the thickness, size and flap shape of the envelopes you are using.

Downloaded from ManualsPrinter.com Manuals

How to load envelopes and postcards

1. Before loading, press the corners and sides of envelopes or post cards to make them as flat as possible.

Note

If envelopes or post cards are ‘double-feeding,’ put one envelope or post card in the paper tray at a time.



2. Put envelopes or post cards in the paper tray with the address side down and the leading edge (top of the envelopes) in first. With both hands, gently press and slide the paper side guides (1) and paper length guide (2) to fit the size of the envelopes or post cards.



Downloaded from ManualsPrinter.com Manuals

If you have problems when printing on envelopes, try the following suggestions:

1. Make sure the flap is either to the side of the envelope or to the back edge of the envelope when printing.
2. Adjust the size and margin in your application.





Loading photo paper

Use the photo paper tray which has been assembled on the top of the paper tray cover to print on Photo 10 × 15 cm and Photo L size paper. When you use the photo paper tray, you do not have to take out the paper that is in the tray beneath it.

1. Squeeze the blue photo paper tray release button (1) using your right index finger and thumb and push the photo paper tray forward until it clicks into the photo printing position (2).



3 Photo Paper Tray

2. Press and slide the paper side guides (1) and paper length guide (2) to fit the paper size.



Downloaded from ManualsPrinter.com Manuals

3 Put the photo paper into the photo paper tray and gently adjust the paper side guides to the paper.
Make sure the paper side guides touch the sides of the paper.

Note

- Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.
- Always make sure that the paper is not curled.

4 When you have finished printing photos return the photo paper tray to the normal printing position.
Squeeze the blue photo paper tray release button (1) using your right index finger and thumb and pull the photo paper tray backward until it clicks (2).



Removing small printouts from the machine

When the machine ejects small paper onto the paper tray you may not be able to reach it. Make sure printing has finished, and then pull the tray completely out of the machine.



Downloaded from ManualsPrinter.com Manuals

Printable area

The printable area depends on the settings in the application you are using. The figures below show the unprintable areas on cut sheet paper and envelopes. The machine can print in the shaded areas of cut sheet paper when the Borderless print feature is available and turned on. (See *Printing* for Windows® or *Printing and Faxing* for Macintosh® in the Software User's Guide on the CD-ROM.)

Cut Sheet Paper



Envelopes



	Top (1)	Bottom (2)	Left (3)	Right (4)
Cut Sheet	3 mm	3 mm	3 mm	3 mm
Envelopes	12 mm	24 mm	3 mm	3 mm

Note

The Borderless feature is not available for envelopes.

Downloaded from ManualsPrinter.com Manuals

Acceptable paper and other print media

The print quality can be affected by the type of paper you use in the machine.

To get the best print quality for the settings you have chosen, always set the Paper Type to match the type of paper you load.

You can use plain paper, inkjet paper (coated paper), glossy paper, transparencies and envelopes.

We recommend testing various paper types before buying large quantities.

For best results, use the Brother paper.

- When you print on inkjet paper (coated paper), transparencies and glossy paper, be sure to choose the correct print media in the '**Basic**' tab of the printer driver or in the Paper Type setting of the menu (See *Paper Type* on page 30).
- When you print on Brother Photo paper, load one extra sheets of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.
- When you use transparencies or photo paper, remove each sheet at once to prevent smudging or paper jams.
- Avoid touching the printed surface of the paper immediately after printing; the surface may not be completely dry and may stain your fingers.

Recommended print media

To get the best print quality, we suggest using Brother paper. (See table below.)

If Brother paper is not available in your country, we recommend testing various papers before purchasing large quantities.

We recommend using '3M Transparency Film' when you print on transparencies.

Brother paper

Paper Type	Item
A4 Plain	BP60PA
A4 Glossy Photo	BP71GA4
A4 Inkjet (Matte)	BP60MA
10 x 15 cm Glossy	BP71GP

Handling and using print media

- Store paper in its original packaging, and keep it sealed. Keep the paper flat and away from moisture, direct sunlight and heat.
- Avoid touching the shiny (coated) side of photo paper. Load photo paper with the shiny side facing down.
- Avoid touching either side of transparencies because they absorb water and perspiration easily, and this may cause decreased output quality. Transparencies designed for laser printers/copiers may stain your next document. Use only transparencies recommended for inkjet printing.
- You can only print on both sides of the paper with PC printing. See *Printing* for Windows® in the Software User's Guide on the CD-ROM.

Downloaded from ManualsPrinter.com Manuals

Improper Setup

DO NOT use the following kinds of paper:

- Damaged, curled, wrinkled, or irregularly shaped paper



1 2 mm or greater

- Extremely shiny or highly textured paper
- Paper that cannot be arranged uniformly when stacked
- Paper made with a short grain

Paper capacity of the paper tray

Up to 50 sheets of 20 lb Letter or 80 g/m^2 A4 paper.

- Transparencies and photo paper must be picked up from the paper tray one page at a time to avoid smudging.

Downloaded from ManualsPrinter.com Manuals

Choosing the right print media

Paper type and size for each operation

Paper Type	Paper Size		Usage		
			Copy	Photo Capture	Printer
Cut Sheet	Letter	216 × 279 mm (8 1/2 × 11 in.)	Yes	Yes	Yes
	A4	210 × 297 mm (8.3 × 11.7 in.)	Yes	Yes	Yes
	Legal	216 × 356 mm (8 1/2 × 14 in.)	Yes	–	Yes
	Executive	184 × 267 mm (7 1/4 × 10 1/2 in.)	–	–	Yes
	JIS B5	182 × 257 mm (7.2 × 10.1 in.)	–	–	Yes
	A5	148 × 210 mm (5.8 × 8.3 in.)	Yes	–	Yes
	A6	105 × 148 mm (4.1 × 5.8 in.)	–	–	Yes
Cards	Photo	10 × 15 cm (4 × 6 in.)	Yes	Yes	Yes
	Photo L	89 × 127 mm (3 1/2 × 5 in.)	–	–	Yes
	Photo 2L	13 × 18 cm (5 × 7 in.)	–	Yes	Yes
	Index Card	127 × 203 mm (5 × 8 in.)	–	–	Yes
	Post Card 1	100 × 148 mm (3.9 × 5.8 in.)	–	–	Yes
	Post Card 2 (Double)	148 × 200 mm (5.8 × 7.9 in.)	–	–	Yes
Envelopes	C5 Envelope	162 × 229 mm (6.4 × 9 in.)	–	–	Yes
	DL Envelope	110 × 220 mm (4.3 × 8.7 in.)	–	–	Yes
	COM-10	105 × 241 mm (4 1/8 × 9 1/2 in.)	–	–	Yes
	Monarch	98 × 191 mm (3 7/8 × 7 1/2 in.)	–	–	Yes
	JE4 Envelope	105 × 235 mm (4.1 × 9.3 in.)	–	–	Yes
Transparencies	Letter	216 × 279 mm (8 1/2 × 11 in.)	Yes	–	Yes
	A4	210 × 297 mm (8.3 × 11.7 in.)	Yes	–	Yes

Downloaded from ManualsPrinter.com Manuals

Paper weight, thickness and capacity

Paper Type		Weight	Thickness	No. of sheets
Cut Sheet	Plain Paper	64 to 120 g/m^2	0.08 to 0.15 mm	100 [1]
	Inkjet Paper	64 to 200 g/m^2	0.08 to 0.25 mm	20
	Glossy Paper	Up to 220 g/m^2	Up to 0.25 mm	20 [2]
Cards	Photo Card	Up to 220 g/m^2	Up to 0.25 mm	20 [2]
	Index Card	Up to 120 g/m^2	Up to 0.15 mm	30
	Post Card	Up to 200 g/m^2	Up to 0.25 mm	30
Envelopes		75 to 95 g/m^2	Up to 0.52 mm	10
Transparencies		–	–	10

[1] Up to 100 sheets of 80 g/m^2 (20 lb) paper.

[2] For Photo 10×15cm paper and Photo L paper, use the photo paper tray. (See *Loading photo paper* on page 13.)

Downloaded from ManualsPrinter.com Manuals

Loading documents

You can make copies and scan from the scanner glass.

Using the scanner glass

You can use the scanner glass to copy or scan pages of a book or one page at a time.

Document Sizes Supported

Length:	Up to 297 mm
Width:	Up to 215.9 mm
Weight:	Up to 2 kg

How to load documents

1. Lift the document cover.
2. Using the document guidelines on the left and top, place the document face down in the upper left corner of the scanner glass.





3. Close the document cover.

CAUTION

If you are scanning a book or thick document, DO NOT slam the cover down or press on it.

Scannable area

The scannable area depends on the settings in the application you are using. The figures below show the areas you cannot scan on A4 or Letter paper.



Usage	Document Size	Top (1) Bottom (2)	Left (3) Right (4)
Copy	All paper sizes	3 mm	3 mm
Scan	All paper sizes	3 mm	3 mm

Downloaded from ManualsPrinter.com Manuals

3 General setup

Paper settings

Paper Type

To get the best print quality, set the machine for the type of paper you are using.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Paper Type`.
4. Press ◀ or ▶ to choose `Plain Paper`, `Inkjet Paper`, `Brother BP71`, `Other Glossy` or `Transparency`.
   Press **OK**.
5. Press **Stop/Exit**.

Note

The machine ejects paper with printed surfaces face up onto the paper tray in front of the machine. When you use transparencies or glossy paper, remove each sheet at once to prevent smudging or paper jams.

Paper Size

You can use five sizes of paper for printing copies: Letter, Legal, A4, A5, and 10 × 15 cm. When you load a different size of paper in the machine, you will need to change the paper size setting at the same time.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Paper Size`.
4. Press ◀ or ▶ to choose `A4`, `A5`, `10x15cm`, `Letter` or `Legal`.
   Press **OK**.
5. Press **Stop/Exit**.

Downloaded from ManualsPrinter.com Manuals

Sleep Mode

You can choose how long the machine must be idle (from 1 to 60 minutes) before it goes into sleep mode. The timer will restart if any operation is carried out on the machine.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Sleep Mode`.
4. Press ◀ or ▶ to choose `1 Min`, `2 Mins`, `3 Mins`, `5 Mins`, `10 Mins`, `30 Mins` or `60 Mins` which is the length of time the machine is idle before entering sleep mode.
   Press **OK**.
5. Press **Stop/Exit**.

LCD display

Changing LCD language

You can change the LCD language.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `Initial Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Local Language`.
   Press **OK**.
4. Press ▲ or ▼ to choose your language.
   Press **OK**.
5. Press **Stop/Exit**.

LCD Contrast

You can adjust the LCD contrast for a sharper and more vivid display. If you are having difficulty reading the LCD, try changing the contrast setting.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `LCD Settings`.
   Press **OK**.
4. Press ▲ or ▼ to choose `LCD Contrast`.
5. Press ◀ or ▶ to choose `Light`, `Med` or `Dark`.
   Press **OK**.
6. Press **Stop/Exit**.

Downloaded from ManualsPrinter.com Manuals

Setting the backlight brightness

If you are having difficulty reading the LCD, try changing the brightness setting.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `LCD Settings`.
   Press **OK**.
4. Press ▲ or ▼ to choose `Backlight`.
5. Press ◀ or ▶ to choose `Light`, `Med` or `Dark`.
   Press **OK**.
6. Press **Stop/Exit**.

Setting the Dim Timer for the backlight

You can set how long the LCD backlight stays on for after the last key is pressed.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `General Setup`.
   Press **OK**.
3. Press ▲ or ▼ to choose `LCD Settings`.
   Press **OK**.
4. Press ▲ or ▼ to choose `Dim Timer`.
5. Press ◀ or ▶ to choose `10 Secs`, `20 Secs`, `30 Secs` or `Off`.
   Press **OK**.
6. Press **Stop/Exit**.

Printing Reports

The following reports are available:

- `Help List`

  A help list showing how to program your machine.

- `User Settings`

  Lists your settings.

- `Network Config` (DCP-585CW only)

  Lists your Network settings.

How to print a report

1. Press **Menu**.
2. Press ▲ or ▼ to choose `Print Reports`.
   Press **OK**.
3. Press ▲ or ▼ to choose the report you want.
   Press **OK**.
4. Press **Mono Start**.
5. Press **Stop/Exit**.

Downloaded from ManualsPrinter.com Manuals

Downloaded from ManualsPrinter.com Manuals

Section II

Copy

Making copies 26

Downloaded from ManualsPrinter.com Manuals

4 Making copies

How to copy

Making a single copy

1. Load your document.
(See *Loading documents* on page 20.)
2. Press **Mono Start** or **Colour Start**.

Making multiple copies

You can make up to 99 copies in one print run.

1. Load your document.
(See *Loading documents* on page 20.)
2. Press **+** or **-** repeatedly until the number of copies you want appears (up to 99).
3. Press **Mono Start** or **Colour Start**.

Stop copying

To stop copying, press **Stop/Exit**.

Copy options

You can change the copy settings from the default display. The LCD shows:



1 No of Copies

You can enter the number of copies you want by pressing **+** or **-** repeatedly.

Press ▲ or ▼ to scroll through the copy options menu.

- Quality (See page 27.)
- Enlarge/Reduce (See page 27.)
- Paper Type (See page 30.)
- Paper Size (See page 30.)
- Brightness (See page 29.)
- Contrast (See page 29.)
- Page Layout (See page 28.)
- Book Copy (See page 30.)
- Watermark Copy (See page 31.)
- Set New Default (See page 32.)
- Factory Reset (See page 32.)

When the option you want is highlighted, press **OK**.

Note

Book Copy and Watermark Copy features are supported by technology from Reallusion, Inc.

You can change the copy settings temporarily for the next copy.

The machine returns to its default settings after 1 minute.

Downloaded from ManualsPrinter.com Manuals

If you have finished choosing settings, press **Mono Start** or **Colour Start**.

If you want to choose more settings, press ▲ or ▼.

Note

You can save some of the settings that you use most often by setting them as default. These settings will stay until you change them again. (See *Setting your changes as a new default* on page 32.)

Changing copy speed and quality

You can choose the copy quality. The factory setting is `Normal`.

`Fast`	Fast copy speed and lowest amount of ink used. Use this setting to save time (documents to be proof read, large documents or many copies).
`Normal`	Recommended setting for ordinary print outs. Good copy quality with adequate copy speed.
`Best`	Use this setting to copy precise images such as photographs. The highest resolution and slowest speed.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Quality`.
4. Press ◀ or ▶ to choose `Fast`, `Normal` or `Best`.
   Press **OK**.
5. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Enlarging or reducing the image copied

You can choose an enlargement or reduction ratio.If you choose `Fit to Page`, your machine will adjust the size automatically to the paper size you set.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Enlarge/Reduce`.
4. Press ◀ or ▶ to choose `Enlarge`, `Reduce`, `Fit to Page`, `Custom(25-400%)`, or `100%`.
5. Do one of the following.
   - If you choose `Enlarge` or `Reduce` press **OK** and press ◀ or ▶ to choose the enlargement or reduction ratio you want. Press **OK** and go to step ❻.
   - If you choose `Custom(25-400%)`, press **OK**. Press **+** or **-** to enter an enlargement or reduction ratio from `25%` to `400%`. Press **OK**. Go to step ❻.
   - If you choose `100%` or `Fit to Page`, press **OK**. Go to step ❻.

`198% 10x15cm→A4`
`186% 10x15cm→LTR`
`142% A5→A4`
`97% LTR→A4`
`93% A4→LTR`
`83%`
`69% A4→A5`
`47% A4→10x15cm`
`Fit to Page`
`Custom(25-400%)`
`100%`

Downloaded from ManualsPrinter.com Manuals

6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Note

- `Page Layout` is not available with `Enlarge/Reduce`.
- `Fit to Page` options are not available with `Page Layout`, `Book Copy` and `Watermark Copy`.
- `Fit to Page` does not work properly if the document on the scanner glass is skewed by more than 3 degrees. Using the document guidelines on the left and top, place your document in the upper left hand corner, with the document face down on the scanner glass.
- `Fit to Page` options are not available when using Legal size paper.

Making N in 1 copies or a poster (Page Layout)

The N in 1 copy feature can help you save paper by letting you copy two or four pages onto one printed page.

You can also make a poster. When you use the poster feature your machine divides your document into sections, then enlarges the sections so you can assemble them into a poster.

Important

- Make sure paper size is set to `Letter` or `A4`.
- You cannot use the `Enlarge/Reduce` setting with the N in 1 and Poster features.
- If you are producing multiple colour copies, N in 1 copy is not available.
- (`P`) means Portrait and (`L`) means Landscape.
- You can only make one poster copy at a time.

Note

`Watermark Copy`, `Book Copy` and `Enlarge/Reduce` are not available with `Page Layout`.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Page Layout`.
4. Press ◀ or ▶ to choose `Off(1 in 1)`, `2 in 1 (P)`, `2 in 1 (L)`, `4 in 1 (P)`, `4 in 1 (L)` or `Poster(3 x 3)`.
   Press **OK**.
5. If you do not want to change additional settings, press **Mono Start** or **Colour Start** to scan the page.
   If you are making a poster the machine scans the pages and starts printing.
   Go to ❻.
6. After the machine scans the page, press **+** (`Yes`) to scan the next page.
7. Place the next page on the scanner glass.
   Press **OK**.
   Repeat ❻ and ❼ for each page of the layout.
8. After all the pages have been scanned, press **-** (`No`) to finish.

Downloaded from ManualsPrinter.com Manuals

Place your document face down in the direction shown below.

■ **2 in 1 (P)**

■ **2 in 1 (L)**



■ **4 in 1 (P)**

■ **4 in 1 (L)**

■ **Poster (3 x 3)**

You can make a poster size copy of a photograph.



Adjusting Brightness and Contrast

Brightness

You can adjust the copy brightness to make copies darker or lighter.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Brightness`.
4. Press ◀ to or ▶ to make a lighter or a darker copy.
   Press **OK**.
5. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Contrast

You can adjust the copy contrast to help an image look sharper and more vivid.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Contrast`.
4. Press ◀ or ▶ to increase or decrease the contrast.
   Press **OK**.
5. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Downloaded from ManualsPrinter.com Manuals

Paper options

Paper Type

If you are copying on special paper, set the machine for the type of paper you are using to get the best print quality.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Paper Type`.
4. Press ◀ or ▶ to choose `Plain Paper`, `Inkjet Paper`, `Brother BP71`, `Other Glossy` or `Transparency`.
   Press **OK**.
5. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Paper Size

If copying on paper other than A4 size, you will need to change the paper size setting.

You can copy only on Letter, Legal, A4, A5 or Photo 10 cm × 15 cm paper.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Paper Size`.
4. Press ◀ or ▶ to choose `Letter`, `Legal`, `A4`, `A5` or `10x15cm`.
   Press **OK**.
5. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Book Copy

Book copy corrects dark borders and skew. Your machine can correct the data automatically or you can make specific corrections.

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Book Copy`.
4. Do one of the following:
   - If you want to correct the data yourself, press ◀ or ▶ to choose `On(Preview)`.
     Press **OK**.
     Press **Mono Start** or **Colour Start** and go to step ❺.
   - If you want the machine to correct the data automatically, press ◀ or ▶ to choose `On` and go to step ❻.
5. Adjust the skewed data using ◀ or ▶. Remove the shadows by using ▲ or ▼.
6. If you have finished making corrections, press **Mono Start** or **Colour Start**.

Note

`Book Copy` is not available with `Page Layout`, `Fit to Page` and `Watermark Copy`.

Downloaded from ManualsPrinter.com Manuals

Watermark Copy

You can place a logo or text into your document as a Watermark. You can select one of the template watermarks, data from your media cards or USB Flash memory drive, or scanned data.

Note

`Watermark Copy` is not available with `Fit to Page`,`Page Layout` and `Book Copy`.

Using a template data

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Watermark Copy`.
   Press **OK**.
4. Press ◀ or ▶ to choose `On`.
5. Press ▲ or ▼ to choose `Current Setting`.
   Press **OK**.
6. Press ▲ or ▼ to choose `Template`.
   Press **OK**.
7. Change the settings from the options displayed on the LCD if required.
8. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

Using media cards or a USB Flash memory drive data

1. Load your document.
2. Enter the number of copies you want.
3. Press ▲ or ▼ to choose `Watermark Copy`.
   Press **OK**.
4. Press ◀ or ▶ to choose `On`.
5. Press ▲ or ▼ to choose `Current Setting`.
   Press **OK**.
6. Press ▲ or ▼ to choose `Media`. Insert a media card or USB Flash memory drive.
7. Press **OK** and press ◀ or ▶ to choose the data you want to use for the watermark.
8. Press **OK** and change any additional settings from the options shown on the LCD.
9. If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

CAUTION

DO NOT take out the memory card or USB Flash memory drive while **Photo Capture** is blinking to avoid damaging the card, USB Flash memory drive or data stored on the card.

Downloaded from ManualsPrinter.com Manuals

Using a scanned paper document as your watermark

1. Enter the number of copies you want.
2. Press ▲ or ▼ to choose `Watermark Copy`.
   Press **OK**.
3. Press ◀ or ▶ to choose `On`.
4. Press ▲ or ▼ to choose `Current Setting`.
   Press **OK**.
5. Press ▲ or ▼ to choose `Scan`. Press **OK** and set the page that you want to use as a watermark on the scanner glass.
6. Press **Mono Start** or **Colour Start**.
7. Take out the watermark document you scanned and load the document you want to copy.
8. Press ◀ or ▶ to change the `Transparency` of the watermark.
   Press **OK**.
9. If you do not want to change any additional settings, press **Mono Start** or **Colour Start**.

Note

You cannot enlarge or reduce the scanned watermark.

Setting your changes as a new default

You can save the copy settings for `Quality`, `Enlarge/Reduce`, `Brightness`, `Contrast` and `Page Layout` that you use most often by setting them as the default settings. These settings will stay until you change them again.

1. Press ▲ or ▼ to choose your new setting.
   Press **OK**.
   Repeat this step for each setting you want to change.
2. After changing the last setting, press ▲ or ▼ to choose `Set New Default`.
   Press **OK**.
3. Press **+** to choose `Yes`.
4. Press **Stop/Exit**.

Restoring all settings to the factory settings

You can restore all the settings you have changed back to the factory settings. These settings will stay until you change them again.

1. Press ▲ or ▼ to choose `Factory Reset`.
   Press **OK**.
2. Press **+** to choose `Yes`.
3. Press **Stop/Exit**.

Downloaded from ManualsPrinter.com Manuals

Section III

Direct Photo Printing

Printing photos from a memory card or USB Flash memory drive 34

Printing photos from a camera 52

Downloaded from ManualsPrinter.com Manuals

5 Printing photos from a memory card or USB Flash memory drive

PhotoCapture Center™ Operations

Printing from a memory card or USB Flash memory drive without a PC

Even if your machine is not connected to your computer, you can print photos directly from digital camera media or a USB Flash memory drive. (See *Print Images* on page 37.)

Scanning to a memory card or USB Flash memory drive without a PC

You can scan documents and save them directly to a memory card or USB Flash memory drive. (See *Scan to a memory card or USB Flash memory drive* on page 49.)

Using PhotoCapture Center™ from your computer

You can access a memory card or USB Flash memory drive that is inserted in the front of the machine from your PC.

(See *PhotoCapture Center*™ for Windows® or *Remote Setup & PhotoCapture Center*™ for Macintosh® in the Software User's Guide on the CD-ROM.)

Using a memory card or USB Flash memory drive

Your Brother machine has media drives (slots) for use with the following popular digital camera media: CompactFlash®, Memory Stick®, Memory Stick Pro™, SD, SDHC, xD-Picture Card™ and USB Flash memory drives.

CompactFlash®

Memory Stick®

Memory Stick Pro™

SD, SDHC



xD-Picture Card™



USB Flash memory drive

- miniSD™ can be used with a miniSD™ adapter.
- microSD can be used with a microSD adapter.
- Memory Stick Duo™ can be used with a Memory Stick Duo™ adapter.
- Memory Stick Pro Duo™ can be used with a Memory Stick Pro Duo™ adapter.
- Memory Stick Micro(M2) can be used with a Memory Stick Micro(M2) adapter.
- Adapters are not included with the machine. Contact a third party supplier for adapters.

The PhotoCapture Center™ feature lets you print digital photos from your digital camera at high resolution to get photo quality printing.

Downloaded from ManualsPrinter.com Manuals

Memory cards or a USB Flash memory drive folder structure

Your machine is designed to be compatible with modern digital camera image files and memory cards or USB Flash memory drive; however, please read the points below to avoid errors:

- The image file extension must be .JPG (Other image file extensions like .JPEG, .TIF, .GIF and so on will not be recognized).
- PhotoCapture Center™ printing must be performed separately from PhotoCapture Center™ operations using the PC. (Simultaneous operation is not available.)
- IBM Microdrive™ is not compatible with the machine.
- The machine can read up to 999 files on a memory card or USB Flash memory drive.
- CompactFlash® Type II is not supported.
- This product supports xD-Picture Card™ Type M / Type M+ / Type H (Large Capacity).
- The DPOF file on the memory cards must be in a valid DPOF format. (See *DPOF printing* on page 44.)

Please be aware of the following:

- When printing the Print Index or Print Images, the PhotoCapture Center™ will print all valid images, even if one or more images have been corrupted. Corrupted images will not be printed.
- (memory card users)

  Your machine is designed to read memory cards that have been formatted by a digital camera.

  When a digital camera formats a memory card it creates a special folder into which it copies image data. If you need to modify the image data stored on a memory card with your PC, we recommend that you do not modify the folder structure created by the digital camera. When saving new or modified image files to the memory card we also recommend you use the same folder your digital camera uses. If the data is not saved to the same folder, the machine may not be able to read the file or print the image.
- (USB Flash memory drive users)

  This machine supports USB Flash memory drives that has been formatted by Windows®.

Downloaded from ManualsPrinter.com Manuals

Getting started

Firmly put a memory card or USB Flash memory drive into the correct slot.



1 **USB Flash memory drive**

2 **CompactFlash®**

3 **SD, SDHC**

4 **Memory Stick®, Memory Stick Pro™**

5 **xD-Picture Card™**

CAUTION

The USB direct interface supports only a USB Flash memory drive, a PictBridge compatible camera, or a digital camera that uses the USB mass storage standard. Any other USB devices are not supported.

Photo Capture key indications:



- **Photo Capture** light is on, the memory card or USB Flash memory drive is correctly inserted.
- **Photo Capture** light is off, the memory card or USB Flash memory drive is not correctly inserted.
- **Photo Capture** light is blinking, the memory card or USB Flash memory drive is being read or written to.

CAUTION

DO NOT unplug the power cord or remove the memory card or USB Flash memory drive from the media drive (slot) or USB direct interface while the machine is reading or writing to the memory card or USB Flash memory drive (the **Photo Capture** key is blinking). **You will lose your data or damage the card.**

The machine can only read one device at a time.

Downloaded from ManualsPrinter.com Manuals

Entering PhotoCapture mode

After you insert the memory card or USB Flash memory drive, press the (**Photo Capture**) key to illuminate it in blue and display the PhotoCapture options on the LCD.

The LCD shows:



Press ▲ or ▼ to scroll through the **Photo Capture** key options.

- `View Photo(s)` (See page 37.)
- `Print Index` (See page 38.)
- `Print Photos` (See page 38.)
- `Enhance Photos` (See page 39.)
- `Search by Date` (See page 42.)
- `Print All Photos` (See page 43.)
- `Slide Show` (See page 43.)
- `Trimming` (See page 44.)

Note

If your digital camera supports DPOF printing, see *DPOF printing* on page 44.

When the option you want is highlighted, press **OK**.

Print Images

View Photo(s)

You can preview your photos on the LCD before you print them. If your photos are large files there may be a delay before each photo is displayed on the LCD.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `View Photo(s)`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
4. Press **+** or **-** repeatedly to enter the number of copies you want.
5. Repeat step ❸ and step ❹ until you have chosen all the photos.

Note

Press **Clear/Back** to go back to the previous level.

6. After you have chosen all the photos, do one of the following:
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

5

Downloaded from ManualsPrinter.com Manuals

Print Index (Thumbnails)

The PhotoCapture Center™ assigns numbers for images (such as No.1, No.2, No.3, and so on).



The PhotoCapture Center™ uses these numbers to identify each picture. You can print a thumbnail page. This will show all the pictures on the memory card.

Note

Only file names that are 8 characters or less will be printed correctly on the index sheet.

1. Make sure you have put the memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Print Index`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Layout Format`. Press ◀ or ▶ to choose `6 Images/Line` or `5 Images/Line`.
   Press **OK**.



`6 Images/Line` `5 Images/Line`

Print time for `5 Images/Line` will be slower than `6 Images/Line`, but the quality is better.

4. Press ▲ or ▼ to choose the paper settings, `Paper Type` and `Paper Size`.
   Do one of the following.
   - If you chose `Paper Type`, press ◀ or ▶ to choose the type of paper you are using, `Plain Paper`, `Inkjet Paper`, `Brother BP71` or `Other Glossy`.
     Press **OK**.
   - If you chose `Paper Size`, press ◀ or ▶ to choose the paper size you are using, `A4` or `Letter`.
     Press **OK**.
   - If you do not want to change the paper settings, go to ❺.
5. Press **Colour Start** to print.

Printing Photos

Before you can print an individual image, you have to know the image number.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Print the Index. (See *Print Index (Thumbnails)* on page 38.)
3. Press ▲ or ▼ to choose `Print Photos`.
   Press **OK**.
4. Press ▲ repeatedly to choose the image number that you want to print from the Index page (Thumbnails).
   If you want to choose a two digit number, press ▶ to move the cursor to the next digit.
   (For example, enter 1, ▶, 6 to print image No.16.)
   Press **OK**.

Note

Press ▼ to decrease the image number.

Downloaded from ManualsPrinter.com Manuals

5 Repeat step ❹ until you have entered all the image numbers that you want to print.
(For example, enter **1**, **OK**, **3**, **OK**, **6**, **OK** to print images No.1, No.3 and No.6.)

Note

You can enter up to 12 characters (including commas) for the image numbers you want to print.

6 After you have chosen all the image numbers, press **OK** again.

7 Press **+** or **-** repeatedly to enter the number of copies you want.

8 Do one of the following:

- Change the print settings. (See page 45.)
- If you do not want to change any settings, press **Colour Start** to print.

Enhance Photos

You can edit and add effects to your photos and view them on the LCD before printing.

Note

- After adding each effect, you can enlarge the view of the image by pressing **Ink Management**. To go back to the original size, press **Ink Management** again.
- The Enhance Photos feature is supported by technology from Reallusion, Inc.

REALLUSION

Auto Correct

Auto Correct is available for most photos. The machine decides the suitable effect for your photo.

1 Make sure you have put a memory card or USB Flash memory drive in the correct slot.
Press (**Photo Capture**).

2 Press ▲ or ▼ to choose `Enhance Photos`.
Press **OK**.

3 Press ◀ or ▶ to choose your photo.
Press **OK**.

4 Press ▲ or ▼ to choose `Auto Correct`.
Press **OK**.

5 Press **OK**. Then press **+** or **-** repeatedly to enter the number of copies you want.

6 Do one of the following.

- Press **OK** and change the print settings. (See page 45.)
- If you do not want to change any settings, press **Colour Start** to print.

Note

If `Remove Red-Eye` appears on the LCD, press ▲ to attempt to remove red-eye from your photo.

Downloaded from ManualsPrinter.com Manuals

Enhance Skin-Tone

Enhance Skin-Tone is best used for adjusting portrait photographs. It detects human skin colour in your photos and adjusts the image.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Enhance Photos`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
   Press **OK**.
4. Press ▲ or ▼ to choose `Enhance Skin-Tone`.
   Press **OK**.
5. Do one of the following.
   - Press **OK** if you do not want to change any settings.
   - Press ▲ or ▼ to adjust the effect level manually. Press **OK** when you have finished.
6. Press **+** or **-** repeatedly to enter the number of copies you want.
7. Do one of the following.
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Enhance Scenery

Enhance Scenery is best used for adjusting landscape photographs. It highlights green and blue areas in your photo, so that the landscape looks more sharp and vivid.

1. Make sure you have put the memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Enhance Photos`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
   Press **OK**.
4. Press ▲ or ▼ to choose `Enhance Scenery`.
   Press **OK**.
5. Do one of the following.
   - Press **OK** if you do not want to change any settings.
   - Press ▲ or ▼ to adjust the effect level manually. Press **OK** when you have finished.
6. Press **+** or **-** repeatedly to enter the number of copies you want.
7. Do one of the following.
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Downloaded from ManualsPrinter.com Manuals

Remove Red-Eye

The machine detects eyes in your photos and will attempt to remove red-eye from your photo.

Note

There are some cases when red-eye may not be removed.

- When the face is too small in the image.
- When the face is turning too far up, down, left or right.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Enhance Photos`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
   Press **OK**.
4. Press ▲ or ▼ to choose `Remove Red-Eye`.
   Press **OK**.
   - When `Remove Red-Eye` is successful, the photo with the effect is shown. The adjusted part is shown in a red frame. Press **OK**.
   - When `Remove Red-Eye` is unsuccessful, `Unable to Detect.` is shown.
     Press **OK** to go back to the previous level.

Note

Press ▲ to try `Remove Red-Eye` again.

5. Press **+** or **-** repeatedly to enter the number of copies you want.
6. Do one of the following.
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Monochrome

You can convert your photo to monochrome.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Enhance Photos`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
   Press **OK**.
4. Press ▲ or ▼ to choose `Monochrome`.
   Press **OK**.
5. Press **OK**. Then press **+** or **-** repeatedly to enter the number of copies you want.
6. Do one of the following.
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Downloaded from ManualsPrinter.com Manuals

Sepia

You can convert the colour of your photo to sepia.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Enhance Photos`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
   Press **OK**.
4. Press ▲ or ▼ to choose `Sepia`.
   Press **OK**.
5. Press **OK**. Then press **+** or **-** repeatedly to enter the number of copies you want.
6. Do one of the following.
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Search by Date

You can find your photos based on date.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Search by Date`.
   Press **OK**.
3. Press ▲ or ▼ to choose the date that you want to search from.
   Press **OK**.
4. Press ◀ or ▶ to choose your photo.

Note

You can view photos with other dates by pressing ◀ or ▶ continuously. Press ◀ to view an older photo and ▶ to view a more recent photo.

5. Press **+** or **-** repeatedly to enter the number of copies you want.
6. Repeat step ❹ and step ❺ until you have chosen all your photos.
7. After you have chosen all your photos, do one of the following:
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Downloaded from ManualsPrinter.com Manuals

Print All Photos

You can print all the photos on your memory card or USB Flash memory drive.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Print All Photos`.
   Press **OK**.
3. Press **+** or **-** repeatedly to enter the number of copies you want.
4. Do one of the following:
   - Change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Slide show

You can view all your photos on the LCD using Slide show. You can also choose a photo during the operation.

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Slide Show`.
   Press **OK**.
3. Press **Stop/Exit** to finish Slide show.

Printing a photo during a Slide show

1. Press **OK** to stop at one image while Slide show is operating.
2. Press **+** or **-** repeatedly to enter the number of copies you want.
3. Do one of the following:
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Downloaded from ManualsPrinter.com Manuals

Trimming

You can trim your photo and print a part of the image.

Note

If your photo is very small or has irregular proportions you may not be able to trim the photo. The LCD will display `Image Too Small.` or `Image Too Long.`

1. Make sure you have put a memory card or USB Flash memory drive in the correct slot.
   Press (**Photo Capture**).
2. Press ▲ or ▼ to choose `Trimming`.
   Press **OK**.
3. Press ◀ or ▶ to choose your photo.
   Press **OK**.
4. Adjust the red frame around your photo. The part inside of the red frame will be printed.
   - Press **+** or **-** to enlarge or reduce the frame size.
   - Press each arrow key to move the position of the frame.
   - Press **Ink Management** to rotate the frame.
   - Press **OK** when you have finished adjusting the frame setting.
5. Press **+** or **-** repeatedly to enter the number of copies you want.
6. Do one of the following:
   - Press **OK** and change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

DPOF printing

DPOF stands for Digital Print Order Format.

Major digital camera manufacturers (Canon Inc., Eastman Kodak Company, Fuji Photo Film Co. Ltd., Matsushita Electric Industrial Co. Ltd. and Sony Corporation) created this standard to make it easier to print images from a digital camera.

If your digital camera supports DPOF printing, you will be able to choose on the digital camera display the images and number of copies you want to print.

When a memory card containing DPOF information is put into your machine, you can print the chosen image easily.

1. Make sure you have put a memory card in the correct slot.
   Press (**Photo Capture**). The machine will ask you if you want to use DPOF setting.
2. Press **+** to choose `Yes`.
3. Do one of the following:
   - Change the print settings. (See page 45.)
   - If you do not want to change any settings, press **Colour Start** to print.

Note

An Invalid DPOF File error can occur if the print order that was created on the camera has been corrupted. Delete and recreate the print order using your camera to correct this problem. For instructions on how to delete or recreate the print order, refer to your camera manufacturer's support website or accompanying documentation.

Downloaded from ManualsPrinter.com Manuals

PhotoCapture Center™ print settings

You can change the print settings temporarily for the next print.

The machine returns to its default settings after 3 minutes.

Note

You can save the print settings you use most often by setting them as default.
(See *Setting your changes as a new default* on page 49.)



1 No. of prints

(For View Photo(s), Search by Date, Slide Show)

You can see the total number of photos that will be printed.

(For Print All Photos, Print Photos, Enhance Photos, Trimming)

You can see the number of copies of each photo that will be printed.

(For DPOF printing) This does not appear.

Menu Selections	Options 1	Options 2	Page
Print Quality (Not available for DPOF printing)	Normal/Photo	—	46
Paper Type	Other Glossy/Plain Paper/ Inkjet Paper/Brother BP71	—	46
Paper Size	10x15cm/13x18cm/A4/Letter	(When A4 or Letter is chosen) Max. Size 8 x 10cm 9 x 13cm 10x15cm 13x18cm 15 x 20cm	46
Brightness (Not available when Enhance Photos is chosen)	◄0 Dark Light►	—	47
Contrast (Not available when Enhance Photos is chosen)	◄0- +►	—	47

Downloaded from ManualsPrinter.com Manuals

Menu Selections	Options 1	Options 2	Page
Color Enhance (Not available when Enhance Photos is chosen)	On/Off White Balance◄0-+► Sharpness◄0-+► Color Density◄0-+► Exit	—	47
Cropping	On/Off	—	48
Borderless	On/Off	—	48
Date Print (Not available for DPOF printing)	Off/On	—	48
Set New Default	Yes/No	—	49
Factory Reset	Yes/No	—	49

Print Speed and Quality

1. Press ▲ or ▼ to choose Print Quality.
2. Press ◄ or ► to choose Normal or Photo.
   Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Paper options

Paper Type

1. Press ▲ or ▼ to choose Paper Type.
2. Press ◄ or ► to choose the paper type you are using, Plain Paper, Inkjet Paper, Brother BP71 or Other Glossy.
   Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Paper and print size

1. Press ▲ or ▼ to choose Paper Size.
2. Press ◄ or ► to choose the paper size you are using, Letter, 10x15cm, 13x18cm or A4.
   Press **OK**.
3. If you chose Letter or A4, press **OK**. Then press ◄ or ► to choose the print size.
   Press **OK**.

Example: Printed Position for A4 paper		
1 8 x 10cm	2 9 x 13cm	3 10x15cm
		
4 13x18cm	5 15 x 20cm	6 Max. Size
		

4. If you do not want to change additional settings, press **Colour Start** to print.

Downloaded from ManualsPrinter.com Manuals

Adjusting Brightness, Contrast and Colour

Brightness

1. Press ▲ or ▼ to choose `Brightness`.
2. Press ◀ or ▶ to make a darker or lighter print.
   Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Contrast

You can choose the contrast setting. More contrast will make an image look sharper and more vivid.

1. Press ▲ or ▼ to choose `Contrast`.
2. Press ◀ to ▶ to change the contrast.
   Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Colour Enhancement

You can turn on the colour enhancement feature to print more vivid images. Printing time will be slower.

1. Press ▲ or ▼ to choose `Color Enhance`.
   Press **OK**.
2. Do one of the following:
   - If you want to customize the White Balance, Sharpness or Colour Density, press ◀ or ▶ to choose `On`, and then go to step ❸.
   - If you do not want to customize, press ◀ or ▶ to choose `Off`.

     Press **OK** and then go to step ❻.
3. Press ▲ or ▼ to choose `White Balance`, `Sharpness` or `Color Density`.
4. Press ◀ or ▶ to adjust the degree of the setting.
   Press **OK**.
5. Do one of the following:
   - If you want to customize another colour enhancement, press ▲ or ▼ to choose another option.
   - If you want to change other settings, press ▲ or ▼ to choose `Exit`, and then press **OK**.
6. If you do not want to change additional settings, press **Colour Start** to print.

Note

- **White Balance**

  This setting adjusts the hue of the white areas of an image. Lighting, camera settings and other influences will effect the appearance of white. The white areas of a picture may be slightly pink, yellow or some other colour. By using this setting, you can correct that effect and bring the white areas back to pure white.

- **Sharpness**

  This setting enhances the detail of an image, similar to adjusting the fine focus on a camera. If the image is not in true focus and you cannot see the fine details of the picture, then adjust the sharpness.

- **Colour Density**

  This setting adjusts the total amount of colour in the image. You can increase or decrease the amount of colour in an image to improve a washed out or weak picture.

Downloaded from ManualsPrinter.com Manuals

Cropping

If your photo is too long or wide to fit the available space on your chosen layout, part of the image will automatically be cropped.

The factory setting is `On`. If you want to print the whole image, turn this setting to `Off`. If you are also using the Borderless setting, turn `Borderless` to `Off`. (See *Borderless printing* on page 48.)

1. Press ▲ or ▼ to choose `Cropping`.
2. Press ◀ or ▶ to choose `Off` (or `On`). Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Cropping: On



Cropping: Off



Borderless printing

This feature expands the printable area to the edges of the paper. Printing time will be slightly slower.

1. Press ▲ or ▼ to choose `Borderless`.
2. Press ◀ or ▶ to choose `Off` (or `On`). Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Date Print

You can print the date if it is already in the data on your photo. The date will be printed on the lower right corner. If the data doesn't have the date information, you cannot use this function.

1. Press ▲ or ▼ to choose `Date Print`.
2. Press ◀ or ▶ to choose `On` (or `Off`). Press **OK**.
3. If you do not want to change additional settings, press **Colour Start** to print.

Note

The DPOF setting on your camera must be turned off to use the `Date Print` feature.

Downloaded from ManualsPrinter.com Manuals

Setting your changes as a new default

You can save the print settings you use most often by setting them as the default settings. These settings will stay until you change them again.

1. Press ▲ or ▼ to choose your new setting.
   Press **OK**.
   Repeat this step for each setting you want to change.
2. After changing the last setting, press ▲ or ▼ to choose `Set New Default`.
   Press **OK**.
3. Press **+** to choose `Yes`.
4. Press **Stop/Exit**.

Restoring all settings to the factory settings

You can restore all the settings you have changed to the factory settings. These settings will stay until you change them again.

1. Press ▲ or ▼ to choose `Factory Reset`.
   Press **OK**.
2. Press **+** to choose `Yes`.
3. Press **Stop/Exit**.

Scan to a memory card or USB Flash memory drive

Entering Scan mode

When you want to scan to a memory card or USB Flash memory drive, press (**Scan**).

The LCD shows:


Scan to E-mail
Scan to Image
Scan to OCR
Scan to File
Scan to Media
Scan a document directly to a media card or USB flash memory.
SCAN
Select & Press OK

Press ▲ or ▼ to choose `Scan to Media`.

Press **OK**.

If you are not connected to your computer only the Scan to Media selection will appear on the LCD.

(See *Scanning* for Windows® or Macintosh® in the Software User's Guide on the CD-ROM for details about the other menu options.)

Downloaded from ManualsPrinter.com Manuals

How to scan to a memory card or USB Flash memory drive

You can scan monochrome and colour documents into a memory card or USB Flash memory drive. Monochrome documents will be stored in PDF (*.PDF) or TIFF (*.TIF) file formats. Colour documents may be stored in PDF (*.PDF) or JPEG (*.JPG) file formats. The factory setting is `Color 150 dpi` and the default file format is PDF. The machine automatically creates file names based on the current date.(For details, see Quick Setup Guide.) For example, the fifth image scanned on July 1, 2009 would be named 01070905.PDF. You can change the colour and quality.

Quality	Selectable File Format
`Color 150 dpi`	`JPEG` / `PDF`
`Color 300 dpi`	`JPEG` / `PDF`
`Color 600 dpi`	`JPEG` / `PDF`
`B/W 200x100 dpi`	`TIFF` / `PDF`
`B/W 200 dpi`	`TIFF` / `PDF`

1. Insert a CompactFlash®, Memory Stick®, Memory Stick Pro™, SD, SDHC, xD-Picture Card™ or USB Flash memory drive into your machine.

CAUTION

DO NOT take out the memory card while **Photo Capture** is blinking to avoid damaging the card or USB Flash memory drive or the data stored on them.

2. Load your document.
3. Press (**Scan**).
4. Press ▲ or ▼ to choose `Scan to Media`.
   Press **OK**.
5. Do one of the following.
   - To change the quality, press ▲ or ▼ to choose `Quality`. Go to step 6.
   - Press **Mono Start** or **Colour Start** to start scanning without changing additional settings.
6. Press ◄ or ► to choose `Color 150 dpi`, `Color 300 dpi`, `Color 600 dpi`, `B/W 200x100 dpi` or `B/W 200 dpi`.
   Press **OK**.
7. Do one of the following.
   - To change the file type, go to step 8.
   - Press **Mono Start** or **Colour Start** to start scanning without changing additional settings.
8. Press ▲ or ▼to choose `File Type`.
   Press ◄ or ► to choose `JPEG`, `PDF` or `TIFF`.
   Press **OK**.

Note

- If you chose colour in the `Quality` setting, you cannot choose `TIFF`.
- If you chose monochrome in the `Quality` setting, you cannot choose `JPEG`.

9. Press **Mono Start** or **Colour Start**.

Downloaded from ManualsPrinter.com Manuals

How to set new default

You can set your own default setting.

1. Press (**Scan**).
2. Press ▲ or ▼ to choose `Scan to Media`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Set New Default`.
   Press **OK**.
4. Press **+** to choose `Yes`.
5. Press **Stop/Exit**.

How to reset to factory settings

You can reset the machine to factory settings.

1. Press (**Scan**).
2. Press ▲ or ▼ to choose `Scan to Media`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Factory Reset`.
   Press **OK**.
4. Press **+** to choose `Yes`.
5. Press **Stop/Exit**.

Understanding the Error Messages

Once you are familiar with the types of errors that can occur while you are using PhotoCapture Center™, you can easily identify and troubleshoot any problems.

- `Hub is Unusable.`

  This message will appear if a Hub or USB Flash memory drive with a Hub has been put into the USB direct interface.

- `Media Error`

  This message will appear if you put in a memory card that is either bad or not formatted, or when there is a problem with the media drive. To clear this error, take out the memory card.

- `No File`

  This message will appear if you try to access a memory card or USB Flash memory drive in the drive (slot) that does not contain a .JPG file.

- `Out of Memory`

  This message will appear if you are working with images that are too large for the machine's memory. This message will also appear when a memory card or USB Flash memory drive you are using does not have enough available space for the scanned document.

- `Media is Full.`

  This message will appear if you are trying to save more than 999 files in a memory card or USB Flash memory drive.

- `Unusable Device`

  This message will appear if a USB device or USB Flash memory drive that is not supported has been connected to the USB direct interface. (For more information, visit us at http://solutions.brother.com.)

  This message can also appear if you connect a broken device to the USB direct interface.

Downloaded from ManualsPrinter.com Manuals

6 Printing photos from a camera

Printing photos directly from a PictBridge camera

Your Brother machine supports the PictBridge standard, allowing you to connect to and print photos directly from any PictBridge compatible digital camera.

If your camera is using the USB Mass Storage standard, you can also print photos from a digital camera without PictBridge. See *Printing photos directly from a digital camera (without PictBridge)* on page 53.

PictBridge requirements

To avoid errors, remember the following points:

- The machine and the digital camera must be connected using a suitable USB cable.
- The image file extension must be .JPG (other image file extensions like .JPEG, .TIF, .GIF and so on will not be recognized).
- PhotoCapture Center™ operations are not available when using the PictBridge feature.

Setting your digital camera

Make sure your camera is in PictBridge mode. The following PictBridge settings may be available from the LCD of your PictBridge compatible camera.

Depending on your camera some of these settings may not be available.

Camera Menu Selections	Options
Paper Size	Letter, A4, 10x15cm, Printer Settings (Default setting) [2]
Paper Type	Plain Paper, Glossy Paper, Inkjet Paper, Printer Settings (Default setting) [2]
Layout	Borderless: On, Borderless: Off, Printer Settings (Default setting) [2]
DPOF setting [1]	-
Print Quality	Normal, Fine, Printer Settings (Default setting) [2]
Color Enhancement	On, Off, Printer Settings (Default setting) [2]
Date Print	On, Off, Printer Settings (Default setting) [2]

[1] See *DPOF printing* on page 53 for more details.

[2] If your camera is set to use the Printer Settings (Default setting), the machine will print your photo using the following settings.

Settings	Options
Paper Size	10x15cm
Paper Type	Glossy Paper
Layout	Borderless: On
Print Quality	Fine
Color Enhancement	Off
Date Print	Off

- When your camera does not have any menu selections, those settings are also used.
- The names and availability of each setting depends on the specification of your camera.

Please refer to the documentation supplied with your camera for more detailed information on changing PictBridge settings.

Downloaded from ManualsPrinter.com Manuals

Printing Images

Note

Remove any memory cards or USB Flash memory drive from the machine before connecting a digital camera.

1. Make sure that your camera is turned off. Connect your camera to the USB direct interface (1) on the machine using the USB cable.



1 USB direct interface

2. Turn on the camera.
When the machine has recognized the camera, the LCD shows `Camera Connected`.

3. Choose the photo you want to print following the instructions from your camera.When the machine starts printing a photo, the LCD will show `Printing`.

WARNING

To prevent damage to your machine, do not connect any device other than a digital camera or USB Flash memory drive to the USB direct interface.

DPOF printing

DPOF stands for Digital Print Order Format.

Major digital camera manufacturers (Canon Inc., Eastman Kodak Company, Fuji Photo Film Co. Ltd., Matsushita Electric Industrial Co. Ltd. and Sony Corporation) created this standard to make it easier to print images from a digital camera.

If your digital camera supports DPOF printing, you will be able to choose on the digital camera display the images and number of copies you want to print.

Note

An invalid DPOF File error can occur if the print order that was created on the camera has been corrupted. Delete and recreate the print order using your camera to correct this problem. For instructions on how to delete or recreate the print order, refer to your camera manufacturer's support website or accompanying documentation.

Printing photos directly from a digital camera (without PictBridge)

If your camera supports the USB Mass Storage standard, you can connect your camera in storage mode. This enables you to print photos from your camera.

If you would like to print photos in PictBridge mode, see *Printing photos directly from a PictBridge camera* on page 52.

Note

The name, availability and operation differ among digital cameras. Please refer to the documentation supplied with your camera for detailed information, such as how to switch from PictBridge mode to mass storage mode.

Downloaded from ManualsPrinter.com Manuals

Printing Images

Note

Remove any memory cards or USB Flash memory drive from the machine before connecting a digital camera.

1. Make sure that your camera is turned off. Connect your camera to the USB direct interface (1) on the machine using the USB cable.



1 USB direct interface

2. Turn on the camera.
3. Follow the steps in *Print Images* on page 37.

WARNING

To prevent damage to your machine, do not connect any device other than a digital camera or USB Flash memory drive to the USB direct interface.

Understanding the Error Messages

Once you are familiar with the types of errors that can occur while you are using PictBridge, you can easily identify and troubleshoot any problems.

- `Out of Memory`

  This message will appear if you are working with images that are too large for the machine's memory.

- `Unusable Device`

  This message will appear if you connect a camera that is not using the USB Mass Storage standard. This message will also appear if you connect a broken device to the USB direct interface.

For more detailed solutions see *Error and Maintenance messages* on page 72.

Downloaded from ManualsPrinter.com Manuals

Section IV

Software

Software and Network features 56

Downloaded from ManualsPrinter.com Manuals

7 Software and Network features

The CD-ROM includes the Software User's Guide and Network User's Guide (DCP-585CW only) for features available when connected to a computer (for example, printing and scanning). The guide has easy to use links that, when clicked, will take you directly to a particular section.

You can find information on these features:

- Printing
- Scanning
- ControlCenter3 (for Windows®)
- ControlCenter2 (for Macintosh®)
- PhotoCapture Center™
- Network Printing (DCP-585CW only)
- Network Scanning (DCP-585CW only)
- Wired and Wireless Network (DCP-585CW only)

How to read the HTML User's Guide

This is a quick reference for using the HTML User's Guide.

For Windows®

Note

If you have not installed the software, see *Viewing Documentation* on page 2.

1. From the **Start** menu, point to **Brother**, **DCP-XXXX** (where XXXX is your model number) from the programs group, then click **User's Guides** in HTML format.
2. Click **SOFTWARE USER'S GUIDE** (or **NETWORK USER'S GUIDE**) from the top menu.

3. Click the heading you would like to read from the list at the left of the window.



For Macintosh®

1. Make sure your Macintosh® is turned on. Insert the Brother CD-ROM into your CD-ROM drive.
2. Double-click the **Documentation** icon.
3. Double-click your language folder, and then double-click top.html.
4. Click **SOFTWARE USER'S GUIDE** (or **NETWORK USER'S GUIDE**) in the top menu, and then click the heading you would like to read from the list at the left of the window.



Downloaded from ManualsPrinter.com Manuals

Section V

Appendixes

Safety and Legal	58
Troubleshooting and Routine Maintenance	67
Menu and Features	87
Specifications	101
Glossary	114

Downloaded from ManualsPrinter.com Manuals

A Safety and Legal

Choosing a location

Put your machine on a flat, stable surface that is free of vibration and shocks, such as a desk. Put the machine near a standard grounded electrical socket. Choose a location where the temperature remains between 10° C and 35° C.

WARNING

DO NOT put the machine near heaters, air conditioners, refrigerators, medical equipment, chemicals or water.

DO NOT connect your machine to electrical sockets on the same circuit as large appliances or other equipment that might disrupt the power supply.

CAUTION

- Avoid placing your machine in a high-traffic area.
- Avoid placing your machine on carpet.
- DO NOT expose the machine to direct sunlight, excessive heat, moisture, or dust.
- DO NOT connect your machine to electrical sockets controlled by wall switches or automatic timers.
- Disruption of power can wipe out information in the machine's memory.
- DO NOT tip the machine, or place it on any tilted surface. Doing this may cause ink spillage and internal damage to your machine.



Downloaded from ManualsPrinter.com Manuals

To use the machine safely

Please keep these instructions for later reference and read them before attempting any maintenance.

WARNING

There are high voltage electrodes inside the machine. Before you clean the inside of the machine, make sure you have unplugged the power cord from the electrical socket. Doing this will prevent an electrical shock.



DO NOT handle the plug with wet hands. Doing this may cause an electrical shock.



DO NOT pull on the middle of the AC power cord. Doing this may cause an electrical shock.

DO NOT put your hands on the edge of the machine under the document cover or the scanner cover. Doing this may cause injury.





Downloaded from ManualsPrinter.com Manuals

DO NOT put your hands on the edge of the paper tray under the paper tray cover. Doing this may cause injury.



DO NOT touch the area shaded in the illustration. Doing this may cause injury.



When moving the machine you must lift it from the base, by placing a hand at each side of the unit as shown in the illustration. DO NOT carry the machine by holding the scanner cover or the Jam Clear Cover.





Downloaded from ManualsPrinter.com Manuals

DO NOT use flammable substances, any type of spray liquid or aerosol cleaners to clean the inside or outside of the machine. Doing this may cause a fire or electrical shock.

If the machine becomes hot, releases smoke, or generates any strong smells, immediately turn off the power switch and unplug the machine from the electrical socket. Call your Brother dealer or Brother Customer Service.

If metal objects, water or other liquids get inside the machine, immediately unplug the machine from the electrical socket. Call your Brother dealer or Brother Customer Service.

This product must be installed near an electrical socket that is easily accessible. In case of an emergency, you must unplug the power cord from the electrical socket to shut off the power completely.

This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source or inverter. If you are not sure, contact a qualified electrician.

Always make sure the plug is fully inserted.

DO NOT use the machine if the power cord is frayed or damaged, doing so may cause a fire.

Downloaded from ManualsPrinter.com Manuals

Important safety instructions

1 Read all of these instructions.

2 Save them for later reference.

3 Follow all warnings and instructions marked on the product.

4 DO NOT use this product near water.

5 DO NOT place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.

6 Slots and openings in the cabinet and the back or bottom are provided for ventilation. To ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heater. This product should never be placed in a built-in installation unless adequate ventilation is provided.

7 Use only the power cord supplied with this machine.

8 This product is equipped with a 3-wire grounded plug, a plug having a third (grounded) pin. This plug will only fit into a grounded power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, call your electrician to replace your obsolete outlet. DO NOT defeat the purpose of the grounded plug.

9 DO NOT allow anything to rest on the power cord. DO NOT place this product where people can walk on the cord.

10 DO NOT place anything in front of the machine that will block printing. DO NOT place anything in the path of printing.

11 Wait until pages have exited the machine before picking them up.

12 Unplug this product from the power socket and refer all servicing to Brother Authorized Service Personnel under the following conditions:

- If liquid has been spilled into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally when the operating instructions are followed, adjust only those controls that are covered by the operating instructions. Incorrect adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- If the product has been dropped or the casing has been damaged.
- If the product exhibits a distinct change in performance, indicating a need for service.

13 To protect your product against power surges, we recommend the use of a power protection device (Surge Protector).

14 To reduce the risk of fire, electric shock and injury to people, note the following:

- DO NOT use this product near appliances that use water, a swimming pool, or in a wet basement.
- DO NOT attempt to operate the machine during an electrical storm or gas leak.

Downloaded from ManualsPrinter.com Manuals

IMPORTANT - For your safety

To ensure safe operation, the supplied three-pin plug must be inserted only into a standard three-pin electrical socket that is effectively grounded through the normal household wiring.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, consult a qualified electrician.

Wiring information (U.K. only)

Important

If you need to replace the plug fuse, fit a fuse that is approved by ASTA to BS1362 with the same rating as the original fuse.

Always replace the fuse cover. Never use a plug that does not have a cover.

Warning - This machine must be earthed.

The wires in the mains lead are coloured in line with the following code:

- **Green and Yellow: Earth**
- **Blue: Neutral**
- **Brown: Live**

If in any doubt, call a qualified electrician.

LAN connection (DCP-585CW only)

CAUTION

DO NOT connect this product to a LAN connection that is subject to over-voltages.

Radio interference

This product complies with EN55022 (CISPR Publication 22)/class B. When connecting the machine to a computer, ensure that you use a USB cable which does not exceed 2.0 metres in length.

Downloaded from ManualsPrinter.com Manuals

EU Directive 2002/96/EC and EN50419

European
Union Only

This equipment is marked with the above recycling symbol. It means that at the end of the life of the equipment you must dispose of it separately at an appropriate collection point and not place it in the normal domestic unsorted waste stream. This will benefit the environment for all. (European Union only)

International ENERGY STAR® Compliance Statement

The purpose of the International ENERGY STAR® Program is to promote the development and popularization of energy-efficient office equipment.

As an ENERGY STAR® Partner, Brother Industries, Ltd. has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

Downloaded from ManualsPrinter.com Manuals

Legal limitations for copying

It is an offence to make reproductions of certain items or documents with the intent to commit fraud. This memorandum is intended to be a guide rather than a complete list. We suggest you check with relevant legal authorities if in doubt about a particular item or document.

The following are examples of documents which may not be copied:

- Money
- Bonds or other certificates of indebtedness
- Certificates of Deposit
- Armed Forces Service or Draft papers.
- Passports
- Postage Stamps (cancelled or uncancelled)
- Immigration Papers
- Welfare documents
- Cheques or Drafts drawn by Governmental Agencies
- Identification Documents, badges or insignias
- Licences and Certificates of Title to motor vehicles

Copyrighted works cannot be copied. Sections of a copyrighted work can be copied for ‘fair dealing’. Multiple copies would indicate improper use.

Works of art should be considered the equivalent of copyrighted works.

Licenses and Certificates of Title to motor vehicles may not be copied under certain state/provincial laws.

Downloaded from ManualsPrinter.com Manuals

Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.

Brother is a registered trademark of Brother Industries, Ltd.

Multi-Function Link is a registered trademark of Brother International Corporation.

© 2008 Brother Industries, Ltd. All rights reserved.

Windows Vista is either a registered trademark or a trademark of Microsoft Corporation in the United States and other countries.

Microsoft, Windows and Windows Server are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Macintosh and TrueType are registered trademarks of Apple Inc.

Nuance, the Nuance logo, PaperPort and ScanSoft are trademarks or registered trademarks of Nuance Communications, Inc. or its affiliates in the United States and/or other countries.

Presto! PageManager is a registered trademark of NewSoft Technology Corporation.

Microdrive is a trademark of International Business Machines Corporation.

CompactFlash is a registered trademark of SanDisk Corporation.

Memory Stick is a registered trademark of Sony Corporation.

SanDisk is a licensee of the SD and miniSD trademarks.

MultiMediaCard is a trademark of Infineon Technologies and licensed to the MultiMediaCard Association.

xD-Picture Card is a trademark of Fujifilm Co. Ltd., Toshiba Corporation and Olympus Optical Co. Ltd.

PictBridge is a trademark.

Memory Stick Pro, Memory Stick Pro Duo, Memory Stick Duo and MagicGate are trademarks of Sony Corporation.

AOSS is a trademark of Buffalo Inc.

BROADCOM, SecureEasySetup and the SecureEasySetup logo are trademarks or registered trademarks of Broadcom Corporation in the United States and/or other countries.

Wi-Fi, WPA and WPA2 are registered trademarks and Wi-Fi Protected Setup is a trademark of Wi-Fi Alliance.

FaceFilter Studio is a trademark of Reallusion, Inc.

Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.

All other brand and product names mentioned in this User's Guide is registered trademarks of their respective companies.

Downloaded from ManualsPrinter.com Manuals

B Troubleshooting and Routine Maintenance

Troubleshooting

If you think there is a problem with your machine, check the chart below and follow the troubleshooting tips.

Most problems can be easily resolved by yourself. If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips. Visit us at http://solutions.brother.com.

If you are having difficulty with your machine

Printing

Difficulty	Suggestions
No printout	Check the interface cable on both the machine and your computer. (See the *Quick Setup Guide*.)
	Make sure the machine is plugged in and not turned off.
	Check to see if the LCD is showing an error message. (See *Error and Maintenance messages* on page 72.)
	One or more ink cartridges are empty. (See *Replacing the ink cartridges* on page 77.)
	If the LCD says `Cannot Print` and `Replace XX Ink` (where XX is an abbreviation of the empty colour), see *Replacing the ink cartridges* on page 77.
	Check that the correct printer driver has been installed and chosen.
	Make sure that the machine is online. Click **Start** and then **Printers and Faxes**. Choose **Brother DCP-XXXX** (where XXXX is your model name), and make sure that **Use Printer Offline** is unchecked.
	When you choose the **Print Odd Pages** and **Print Even Pages** settings, you may see a print error message on your computer, as the machine pauses during the printing process. The error message will disappear after the machine re-starts printing.

Downloaded from ManualsPrinter.com Manuals

Printing (continued)

Difficulty	Suggestions
Poor print quality	Use only Genuine Brother Consumables as ink from other manufactures can cause print quality problems.
	Check the print quality. (See *Checking the print quality* on page 82.)
	Make sure that the Media Type setting in the printer driver or the Paper Type setting in the machine's menu matches the type of paper you are using. (See *Printing* for Windows® or *Printing and Faxing* for Macintosh® in the Software User's Guide on the CD-ROM and *Paper Type* on page 21.)
	Make sure that your ink cartridges are fresh. The following may cause ink to clog: ■ The expiration date written on the cartridge package has passed. (Brother Original cartridge stay usable for up to two years if kept in their original packaging.) ■ The ink cartridge was in your machine over six months. ■ The ink cartridge may not have been stored correctly before use.
	Try using the recommended types of paper. (See *Acceptable paper and other print media* on page 16.)
	The recommended environment for your machine is between 20° C to 33° C.
White horizontal lines appear in text or graphics.	Clean the print head. (See *Cleaning the print head* on page 82.)
	Make sure you are using Brother Original Innobella™ ink.
	Try using the correct types of paper. (See *Acceptable paper and other print media* on page 16.)
	If you want to print on Photo L or 10 × 15 cm paper, make sure you use the photo paper tray. (See *Loading photo paper* on page 13.)
The machine prints blank pages.	Clean the print head. (See *Cleaning the print head* on page 82.)
Characters and lines are stacked.	Check the printing alignment. (See *Checking the print alignment* on page 83.)
Printed text or images are skewed.	Make sure the paper is loaded correctly in the paper tray and the paper side guides are adjusted correctly. (See *Loading paper and other print media* on page 9.)
	Make sure the Jam Clear Cover is closed correctly.
Smudged stain at the top centre of the printed page.	Make sure the paper is not too thick or curled. (See *Acceptable paper and other print media* on page 16.)
Smudged stain at the right or left corner of the printed page.	Make sure the paper is not curled when you print on the back side of the paper with the **Print Odd Pages** and **Print Even Pages** settings.
Printing appears dirty or ink seems to run.	Make sure you are using the recommended types of paper. (See *Acceptable paper and other print media* on page 16.) Don't handle the paper until the ink is dry.
	If you are using photo paper, make sure that you have set the correct paper type. If you are printing a photo from your PC, set the **Media Type** in the **Basic** tab of the printer driver.
	Make sure you are using Brother Original Innobella™ ink.
Stains appear on the reverse side or at the bottom of the page.	Make sure the printer platen is not dirty with ink. (See *Cleaning the machine printer platen* on page 81.)
	Make sure you are using the paper support flap. (See *Loading paper and other print media* on page 9.)
The machine prints dense lines on the page.	Check **Reverse Order** in the **Basic** tab of the printer driver.

Downloaded from ManualsPrinter.com Manuals

Printing (continued)

Difficulty	Suggestions
The printouts are wrinkled.	In the printer driver **Advanced** tab, click **Colour Settings**, and uncheck **Bi-Directional Printing**.
	Make sure you are using Brother Original Innobella™ ink.
Cannot perform 'Page Layout' printing.	Check that the paper size setting in the application and in the printer driver are the same.
Print speed is too slow.	Try changing the printer driver setting. The highest resolution needs longer data processing, sending and printing time. Try the other quality settings in the printer driver **Advanced** tab. Also, click the **Colour Settings**, and make sure you uncheck **Colour Enhancement**.
	Turn the borderless feature off. Borderless printing is slower than normal printing. (See *Printing* for Windows® or *Printing and Faxing* for Macintosh® in the Software User's Guide on the CD-ROM.)
Colour Enhancement is not working correctly.	If the image data is not full colour in your application (such as 256 colour), Colour Enhancement will not work. Use at least 24 bit colour data with the Colour Enhancement feature.
Photo paper does not feed properly.	When you print on Brother Photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.
	Clean the paper pick-up roller. (See *Cleaning the paper pick-up roller* on page 81.)
Machine feeds multiple pages.	Make sure the paper is loaded correctly in the paper tray. (See *Loading paper and other print media* on page 9.)
	Check that more than two types of paper are not loaded in the paper tray at any one time.
Printed pages are not stacked neatly.	Make sure you are using the paper support flap. (See *Loading paper and other print media* on page 9.)
Machine does not print from Adobe Illustrator.	Try to reduce the print resolution. (See *Printing* for Windows® or *Printing and Faxing* for Macintosh® in the Software User's Guide on the CD-ROM.)

Copying Difficulties

Difficulty	Suggestions
Vertical streaks appear on copies.	Vertical black lines or streaks on copies are typically caused by dirt or correction fluid on the scanner. Clean scanner glass and white plastic above it. (See *Cleaning the scanner glass* on page 80.)
Fit to Page does not work properly.	Make sure the document is not skewed on the scanner glass.

Scanning Difficulties

Difficulty	Suggestions
TWAIN/WIA errors appear when starting to scan.	Make sure the Brother TWAIN/WIA driver is chosen as the primary source. In PaperPort™ 11SE with OCR, click **File**, **Scan or Get Photo** and click **Select** to choose the Brother TWAIN/WIA driver.
OCR does not work.	Try increasing the scanner resolution.

Downloaded from ManualsPrinter.com Manuals

Software Difficulties

Difficulty	Suggestions
Cannot install software or print.	Run the **Repair MFL-Pro Suite** program on the CD-ROM. This program will repair and reinstall the software.
'Device Busy'	Make sure the machine is not showing an error message on the LCD.
Cannot print images from FaceFilter Studio.	To use FaceFilter Studio, you must install the FaceFilter Studio application from the CD-ROM supplied with your machine. To install FaceFilter Studio see the *Quick Setup Guide*. Also, before you start FaceFilter Studio for the first time, you must make sure your Brother machine is turned On and connected to your computer. This will allow you to access all the functions of FaceFilter Studio.

PhotoCapture Center™ Difficulties

Difficulty	Suggestions
Removable Disk does not work correctly.	1 Have you installed the Windows® 2000 update? If not, do the following: 1) Unplug the USB cable. 2) Install the Windows® 2000 update using one of the following methods. ■ Install MFL-Pro Suite from the CD-ROM. (See the *Quick Setup Guide*.) ■ Download the latest service pack from the Microsoft Web site. 3) Wait about 1 minute after you restart the PC, and then connect the USB cable. 2 Take out the memory card or USB Flash memory drive and put it back in again. 3 If you have tried 'Eject' from within Windows®, take out the memory card or USB Flash memory drive before you continue. 4 If an error message appears when you try to eject the memory card or USB Flash memory drive, it means the card is being accessed. Wait a while and then try again. 5 If all of the above do not work, turn off your PC and machine, and then turn them on again. (You will have to unplug the power cord of the machine to turn it off.)
Cannot access Removable Disk from Desktop icon.	Make sure that you have correctly inserted the memory card or USB Flash memory drive.
Part of my photo is missing when printed.	Make sure that Borderless Printing and Cropping are turned off. (See *Borderless printing* on page 48, and *Cropping* on page 48.)

Downloaded from ManualsPrinter.com Manuals

Network Difficulties

Difficulty	Suggestions
Cannot print over the Network.	Make sure that your machine is powered on and is online and in Ready mode. Print a Network Configuration list (see *Printing Reports* on page 23) and check the current Network settings printed in this list. Reconnect the LAN cable to the hub to verify that the cabling and network connections are good. If possible, try connecting the machine to a different port on your hub using a different cable. If the connections are good, the machine shows `LAN Active` for 2 seconds. (If you are having Network problems, see the *Network User's Guide* on the CD-ROM for more information.)
The network scanning feature does not work.	(For Windows® users only) Firewall settings on your PC may be rejecting the necessary network connection. Follow the instructions below to configure the Firewall. If you are using personal Firewall software, see the User's Guide for your software or contact the software manufacturer. For Windows® XP SP2 and Windows Vista® users, see *Firewall settings* in the Software User's Guide on the CD-ROM. For Windows® XP SP1 user's, please visit the Brother Solutions Center.
Your computer cannot find your machine.	<Windows® users> Firewall settings on you PC may be rejecting the necessary network connection. For details, see the instruction above. <Macintosh® users> Re-select your machine in the Device Selector application located in Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector or from the model list in ControlCenter2.

Downloaded from ManualsPrinter.com Manuals

Error and Maintenance messages

As with any sophisticated office product, errors may occur. If this happens, your machine identifies the error and shows an error message. The most common error and maintenance messages are shown below.

You can correct most errors and routine maintenance by yourself. If you need more help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at http://solutions.brother.com.

Error Message	Cause	Action
B&W Print Only	One or more of the colour ink cartridges is empty. While this message appears on the LCD, each operation works in the following way: ■ Printing If you click **Greyscale** in the Advanced tab of the printer driver you can use the machine as a monochrome printer for approximately four weeks depending on the number of pages you print. ■ Copying If the paper type is set to Plain Paper or Inkjet Paper you can make copies in monochrome. If the paper type is set to Other Glossy or Brother BP71, the machine will stop all print operations. If you unplug the machine, or take out the empty ink cartridge, you cannot use the machine until you change to a new ink cartridge.	Replace the empty ink cartridges. (See *Replacing the ink cartridges* on page 77.)
Cannot Detect	You installed a new ink cartridge too quickly and the machine did not detect it.	Take out the new ink cartridge and re-install it slowly.
	If you are using non Brother Original ink the machine may not detect the ink cartridge.	Replace the cartridge with a Brother Original ink cartridge. If the error message remains, contact your Brother dealer.
Cannot Print	One or more of the ink cartridges are empty. The machine will stop all print operations.	Replace the empty ink cartridges. (See *Replacing the ink cartridges* on page 77.)

Downloaded from ManualsPrinter.com Manuals

Error Message	Cause	Action
Cover is Open	The scanner cover is not closed completely.	Lift the scanner cover and then close it again.
	The ink cartridge cover is not completely closed.	Firmly close the ink cartridge cover until it clicks.
Data Remaining	Print data is left in the machine's memory.	Press **Stop/Exit**. The machine will cancel the job and clear it from the memory. Try to print again.
High Temperature	The print head is too warm.	Allow the machine to cool down.
Hub is Unusable.	A Hub or USB Flash memory drive with Hub has been connected to the USB direct interface.	A Hub or USB Flash memory drive with Hub are not supported. Unplug the device from the USB direct interface.
Image Too Long.	The proportions of your photo are irregular so effects could not be added.	Choose a regularly proportioned image.
Image Too Small.	The size of your photo is too small to trim.	Choose a larger image.
Ink low	One or more of the ink cartridges are running out of ink.	Order a new ink cartridge.
Low Temperature	The print head is too cold.	Allow the machine to warm up.
Media Error	The memory card is either corrupted, incorrectly formatted, or there is a problem with the memory card.	Put the card firmly into the slot again to make sure it is in the correct position. If the error remains, check the media drive (slot) of the machine by putting in another memory card that you know is working.
Media is Full.	The memory card or USB Flash memory drive you are using already contains 999 files.	Your machine can only save to your memory card or USB Flash memory drive if it contains less than 999 files. Try deleting unused files to free some space and try again.
No Cartridge	An ink cartridge is not installed correctly.	Take out the ink cartridge and put it in again seating it properly. (See *Replacing the ink cartridges* on page 77.)
No File	The memory card or USB Flash memory drive in the media drive does not contain a .JPG file.	Put the correct memory card or USB Flash memory drive into the slot again.

Downloaded from ManualsPrinter.com Manuals

Error Message	Cause	Action
No Paper Fed	The machine is out of paper or paper is not properly loaded in the paper tray.	Do one of the following: ■ Refill the paper in the paper tray, and then press **Mono Start** or **Colour Start**. ■ Remove the paper and load it again and then press **Mono Start** or **Colour Start**.
	The Jam Clear Cover is not closed properly.	Check that the Jam Clear Cover is closed. (See *Printer jam or paper jam* on page 75.)
	The paper is jammed in the machine.	See *Printer jam or paper jam* on page 75.
Out of Memory	The machine's memory is full.	**Copy operation in progress** Press **Stop/Exit** and wait until the other operations in progress finish and then try again.
	The memory card or USB Flash memory drive you are using does not have enough free space to scan the documents.	Delete unused files from your memory card or USB Flash memory drive to make some free space and then try again.
Paper Jam	Paper is jammed in the machine.	Remove the jammed paper by following the steps in *Printer jam or paper jam* on page 75.
		Make sure the paper length guide is adjusted to the correct paper side.
Unable to CleanXX Unable to Init. XX Unable to Print XX Unable to Scan XX	The machine has a mechanical problem. –OR– A foreign object such as a clip or ripped paper is in the machine.	Open the scanner cover and look on the left, middle and right hand side under the covers for foreign objects and paper scraps. If the error message continues, disconnect the machine from the power for several minutes, then reconnect it.
Unusable Device Disconnect device from front connector & turn machine off & then on	A broken device has been connected to the USB direct interface.	Unplug the device from the USB direct interface, then press **On/Off** to turn the machine off and then on again.
Unusable Device Please Disconnect USB Device.	A USB device or USB Flash memory drive that is not supported has been connected to the USB direct interface. For more information, visit us at http://solutions.brother.com	Unplug the device from the USB direct interface.
Wrong Paper Size	Paper is not the correct size.	Check that the machine's "Paper Size" setting matches the size of paper in the tray. (See *Paper Size* on page 21.)

Downloaded from ManualsPrinter.com Manuals

Error animation

Error animation displays step-by-step instructions when paper gets jammed or ink cartridges become empty. You can read the steps at your own pace by pressing ▶ to see the next step and ◀ to go backward. If you do not press a key, after 1 minute the animation starts running automatically again.

Note

You can press ▶, ◀ or **OK** to pause the auto-animation and go back to step-by-step mode.

Printer jam or paper jam

Take out the jammed paper depending on where it is jammed in the machine. Open and close the scanner cover to clear the error.

1. Pull the paper tray (1) out of the machine.



2. Pull out the jammed paper (1).



- If you cannot remove the jammed paper from the front, or the error message still appears on the LCD after you have removed the jammed paper, please go to the next step.

3. Reset the machine by lifting the scanner cover from the front of the machine and then close it.

- If you cannot remove the jammed paper from the front of the machine, or the error message still appears on the LCD after you have removed the jammed paper, please go to the next step.

4. Open the Jam Clear Cover (1) at the back of the machine. Pull the jammed paper out of the machine.





B

Downloaded from ManualsPrinter.com Manuals

5 Close the Jam Clear Cover.
Make sure the cover is closed properly.



6 Using both hands, use the finger holds on both sides of the machine to lift the scanner cover (1) until it locks securely in the open position.
Make sure that there is no jammed paper left inside the machine. Check both ends of the print carriage.



Note

- If the paper is jammed under the print head, unplug the machine from the power source, and then move the print head to take out the paper.
- If the print head has stopped in the right corner like the illustration, you cannot move the print head. Hold down **Stop/Exit** until the print head moves to the middle. Then unplug the machine from the power source, and take out the paper.



- If ink gets on your skin or clothing immediately wash it off with soap or detergent.

7 Lift the scanner cover to release the lock (1). Gently push the scanner cover support down (2) and close the scanner cover (3) using both hands.



Downloaded from ManualsPrinter.com Manuals

8 Push the paper tray firmly back into the machine. While holding the paper tray in place, pull out the paper support until it clicks and unfold the paper support flap.

Note

Make sure you pull out the paper support until it clicks.



Routine maintenance

Replacing the ink cartridges

Your machine is equipped with an ink dot counter. The ink dot counter automatically monitors the level of ink in each of the 4 cartridges. When the machine detects an ink cartridge is running out of ink, the machine will tell you with a message on the LCD.

The LCD will tell you which ink cartridge is low or needs replacing. Be sure to follow the LCD prompts to replace the ink cartridges in the correct order.

Even though the machine tells you that an ink cartridge is empty, there will be a small amount of ink left in the ink cartridge. It is necessary to keep some ink in the ink cartridge to prevent air from drying out and damaging the print head assembly.

CAUTION

Brother multifunction machines are designed to work with ink of a particular specification and will work to a level of optimum performance and reliability when used with genuine Brother Branded ink cartridges. Brother cannot guarantee this optimum performance and reliability if ink or ink cartridges of other specifications are used. Brother does not therefore recommend the use of cartridges other than genuine Brother Branded cartridges or the refilling of empty cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using other brands of ink or ink cartridges, any repairs required as a result may not be covered by the warranty.

1 Open the ink cartridge cover.
If one or more ink cartridges are empty, for example Black, the LCD shows `Cannot Print` and `Replace Ink` BK.

Downloaded from ManualsPrinter.com Manuals

2 Press the lock release lever as shown to release the cartridge indicated on the LCD. Remove the cartridge from the machine.





3 Open the new ink cartridge bag for the colour shown on the LCD, and then take out the ink cartridge.

4 Turn the green knob on the protective yellow cap clockwise until it clicks to release the vacuum seal, then remove the cap (1).



5 Each colour has its own correct position. Insert the ink cartridge in the direction of the arrow on the label.



Downloaded from ManualsPrinter.com Manuals

6 Gently push the ink cartridge until it clicks, and then close the ink cartridge cover.



7 The machine will automatically reset the ink dot counter.

Note

- If you replaced an ink cartridge, for example Black, the LCD may ask you to verify that it was a brand new one (`Did You Change` BK `Black`). For each new cartridge you installed, press **+** (`Yes`) to automatically reset the ink dot counter for that colour. If the ink cartridge you installed is not a brand new one, be sure to press **-** (`No`).
- If the LCD shows `No Cartridge` or `Cannot Detect` after you install the ink cartridges, check that the ink cartridges are installed correctly.

WARNING

If ink gets in your eyes, wash them out with water at once and call a doctor if you are concerned.

CAUTION

DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.

DO NOT touch the cartridge insertion slots. If you do so, the ink may stain your skin.

If ink gets on your skin or clothing immediately wash it off with soap or detergent.

If you mix the colours by installing an ink cartridge in the wrong position, clean the print head several times after correcting the cartridge installation.

Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.

DO NOT dismantle or tamper with the ink cartridge, this can cause the ink to leak out of the cartridge.

Downloaded from ManualsPrinter.com Manuals

Cleaning the outside of the machine

CAUTION

Use neutral detergents. Cleaning with volatile liquids such as thinner or benzine will damage the outside surface of the machine.

DO NOT use cleaning materials that contain ammonia.

DO NOT use isopropyl alcohol to remove dirt from the control panel. It may crack the panel.

Clean the outside of the machine as follows:

1. Pull the paper tray (1) completely out of the machine.



2. Wipe the outside of the machine with a soft cloth to remove dust.



3. Lift the paper tray cover and remove anything that is stuck inside the paper tray.

4. Wipe the inside and outside of the paper tray with a soft cloth to remove dust.



5. Close the paper tray cover and put the paper tray firmly back in the machine.

Cleaning the scanner glass

1. Lift the document cover (1). Clean the scanner glass (2) and the white plastic (3) with a soft lint-free cloth moistened with a non-flammable glass cleaner.



Downloaded from ManualsPrinter.com Manuals

Cleaning the machine printer platen

WARNING

Be sure to unplug the machine from the electrical socket before cleaning the printer platen (1).

1. Lift the scanner cover until it locks securely into the open position.
2. Clean the machine printer platen (1) and the area around it, wiping off any scattered ink with a safe, dry lint-free cloth.



Cleaning the paper pick-up roller

1. Pull the paper tray completely out of the machine.
2. Unplug the machine from the electrical socket and open the Jam Clear Cover (1) at the back of the machine.



3. Clean the paper pick-up roller (1) with isopropyl alcohol on a cotton swab.



4. Close the Jam Clear Cover. Make sure the cover is closed properly.
5. Re-connect the power cord.
6. Slowly push the paper tray completely back into the machine.

B

Downloaded from ManualsPrinter.com Manuals

Cleaning the print head

To maintain print quality, the machine will automatically clean the print head when needed. You can start the cleaning process manually if there is a print quality problem.

Clean the print head and ink cartridges if you get a horizontal line or blank text in the text or graphics on your printed pages. You can clean Black only, three colours at a time (Yellow/Cyan/Magenta), or all four colours at once.

Cleaning the print head consumes ink. Cleaning too often uses ink unnecessarily.

CAUTION

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

1. Press **Ink Management**.
2. Press ▲ or ▼ to choose `Cleaning`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Black`, `Color` or `All`.
   Press **OK**.
   The machine cleans the print head.
   When cleaning is finished, the machine will go back to standby mode automatically.

Note

If you clean the print head at least five times and the print has not improved, try installing a new genuine Brother Branded replacement cartridge for each problem color. Try cleaning the print head again up to five more times. If the print has not improved call your Brother dealer.

Checking the print quality

If faded or streaked colours and text appear on your output, some of the nozzles may be clogged. You can check this by printing the Print Quality Check Sheet and looking at the nozzle check pattern.

1. Press **Ink Management**.
2. Press ▲ or ▼ to choose `Test Print`.
   Press **OK**.
3. Press ▲ or ▼ to choose `Print Quality`.
   Press **OK**.
4. Press **Colour Start**.
   The machine begins printing the Print Quality Check Sheet.
5. Check the quality of the four colour blocks on the sheet.
6. Do one of the following:
   - If all lines are clear and visible, press **+** to choose `Yes`, and go to step ❿.
   - If you can see missing short lines as shown below, press **-** to choose `No`.

OK



Poor



7. The LCD asks you if the print quality is OK for black and three colours.
   Press **+** (`Yes`) or **-** (`No`).
8. The LCD asks you if you want to start cleaning.
   Press **+** (`Yes`).
   The machine starts cleaning the print head.

Downloaded from ManualsPrinter.com Manuals

9 After cleaning is finished, press **Colour Start**.
The machine starts printing the Print Quality Check Sheet again and then returns to step ❺.

10 Press **Stop/Exit**.
If you repeat this procedure at least five times and the print quality is still poor, replace the ink cartridge for the clogged colour.
After replacing the ink cartridge, check the print quality. If the problem still exists, repeat the cleaning and test print procedures at least five times for the new ink cartridge. If ink is still missing, call your Brother dealer.

CAUTION

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

Note

When a print head nozzle is clogged the printed sample looks like this.

After the print head nozzle is cleaned, the horizontal lines are gone.

Checking the print alignment

You may need to adjust the print alignment after transporting the machine if your printed text becomes blurred or images become faded.

1 Press **Ink Management**.

2 Press ▲ or ▼ to choose `Test Print`.
Press **OK**.

3 Press ▲ or ▼ to choose `Alignment`.
Press **OK**.

4 Press **Mono Start** or **Colour Start**.
The machine starts printing the Alignment Check Sheet.

5 Check the 600 dpi and 1200 dpi test prints to see if number 5 most closely matches number 0.

- If the number 5 samples of both the 600 dpi and 1200 dpi test prints are the best matches, press **+** (`Yes`) to finish Alignment Check, and go to step ❽.
- If another test print number is a better match for either 600 dpi or 1200 dpi, press **-** (`No`) to choose it.

6 For 600 dpi, press ◄ or ► to choose the number of the test print that most closely matches the number 0 sample (1-8).
Press **OK**.

7 For 1200 dpi, press ◄ or ► to choose the number of the test print that most closely matches the number 0 sample (1-8).
Press **OK**.

8 Press **Stop/Exit**.

Downloaded from ManualsPrinter.com Manuals

Checking the ink volume

You can check the ink that is left in the cartridge.

1. Press **Ink Management**.
2. Press ▲ or ▼ to choose `Ink Volume`.
   Press **OK**.
   The LCD shows the ink volume.
3. Press **Stop/Exit**.

Note

You can check the ink volume from your computer. (See *Printing* for Windows® or *Printing and Faxing* for Macintosh® in the Software User's Guide on the CD-ROM.)

Machine Information

Checking the serial number

You can see the machine's serial number on the LCD.

1. Press **Menu**.
2. Press ▲ or ▼ to choose `Machine Info.`
   Press **OK**.
3. Press ▲ or ▼ to choose `Serial No.`
   Press **OK**.
4. Press **Stop/Exit**.

Packing and shipping the machine

When you transport the machine, use the packing materials that came with your machine. Follow the instructions below to properly pack your machine. Damage caused to your machine during transit is not covered by your warranty.

CAUTION

It is important to allow the machine to 'park' the print head after a print job. Listen carefully to the machine before unplugging it to make sure that all mechanical noise has stopped. Not allowing the machine to finish this parking process may lead to print problems and possible damage to the print head.

1. Open the ink cartridge cover.
2. Press the ink release lever to release the ink cartridge and take out all the ink cartridges.
   (See *Replacing the ink cartridges* on page 77.)
3. Install the green protective part and then close the ink cartridge cover.



Downloaded from ManualsPrinter.com Manuals

CAUTION

Make sure that the plastic tabs on both sides of the green protective part (1) have securely clicked into place (2).



If you are not able to find the green protective part, DO NOT remove the ink cartridges before shipping. It is essential that the machine be shipped with either the green protective part or the ink cartridges in position. Shipping without them will cause damage to your machine and may void your warranty.

4 Lift the front of the machine and hook the long end (1) of the green protective part into the T-shaped hole underneath the machine. Push the forked end (2) onto the top of the paper tray.



5 Unplug the machine from the electrical socket.

6 Using both hands, use the plastic tabs on both sides of the machine to lift the scanner cover until it locks securely into the open position. Then unplug the interface cable from the machine, if it is connected.

7 Lift the scanner cover to release the lock (1). Gently push the scanner cover support down (2) and close the scanner cover (3).



B

Downloaded from ManualsPrinter.com Manuals

8 Wrap the machine in the bag and put it in the original carton with the original packing material.



9 Pack the printed materials in the original carton as shown below. Do not pack the used ink cartridges in the carton.



10 Close the carton and tape it shut.

Downloaded from ManualsPrinter.com Manuals

C Menu and Features

On-screen programming

Your machine is designed to be easy to operate with LCD on-screen programming using the menu keys. User-friendly programming helps you take full advantage of all the menu selections your machine has to offer.

Since your programming is done on the LCD, we have created step-by-step on-screen instructions to help you program your machine. All you need to do is follow the instructions as they guide you through the menu selections and programming options.

Menu table

You can program your machine by using the Menu table that begins on page 88. These pages list the menu selections and options.

Mode and menu keys

	Access the main menu, PhotoCapture menu or Scan menu.
▲ ▼	Scroll through the current menu level.
◀	Go back to the previous menu level.
▶	Go to the next menu level.
	■ Go to the next menu level. ■ Accept an option.
	Stop the current operation.

Downloaded from ManualsPrinter.com Manuals

Menu table

The menu table will help you understand the menu selections and options that are found in the machine's programs. The factory settings are shown in Bold with an asterisk.

Menu (Menu)

Level 1	Level 2	Level 3	Options	Descriptions	Page
General Setup	**Paper Type**	—	**Plain Paper***	Sets the type of paper in the paper tray.	21
			Inkjet Paper		
			Brother BP71		
			Other Glossy		
			Transparency		
	Paper Size	—	Letter	Sets the size of the paper in the paper tray.	21
			Legal		
			A4*		
			A5		
			10x15cm		
	LCD Settings	**LCD Contrast**	Light	Adjusts the contrast of the LCD.	22
			Med*		
			Dark		
		Backlight	**Light***	You can adjust the brightness of the LCD backlight.	23
			Med		
			Dark		
		Dim Timer	Off	You can set how long the LCD backlight stays on for after the last key press.	23
			10 Secs		
			20 Secs		
			30 Secs*		
	Sleep Mode	—	1 Min	You can choose how long the machine must be idle before it goes into sleep mode.	22
			2 Mins		
			3 Mins		
			5 Mins*		
			10 Mins		
			30 Mins		
			60 Mins		
	The factory settings are shown in Bold with an asterisk.				

Downloaded from ManualsPrinter.com Manuals

Network menu (DCP-585CW only)

Level1	Level2	Level3	Level4	Options	Descriptions
Network	**Wired LAN**	**TCP/IP**	**BOOT Method**	**Auto*** Static RARP BOOTP DHCP	Chooses the BOOT method that best suits your needs.
			IP Address	[000-255]. [000-255]. [000-255]. [000-255]	Enter the IP address.
			Subnet Mask	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Subnet mask.
			Gateway	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Gateway address.
			Node Name	BRNXXXXXXXXXXXX	Enter the Node name.
			WINS Config	**Auto*** Static	Chooses the WINS configuration mode.
			WINS Server	(Primary) 000.000.000.000 (Secondary) 000.000.000.000	Specifies the IP address of the primary or secondary server.
			DNS Server	(Primary) 000.000.000.000 (Secondary) 000.000.000.000	Specifies the IP address of the primary or secondary server.
			APIPA	**On*** Off	Automatically allocates the IP address from the link-local address range.
	See *Network User's Guide on the CD-ROM*.				
	The factory settings are shown in Bold with an asterisk.				

C

Downloaded from ManualsPrinter.com Manuals

Level1	Level2	Level3	Level4	Options	Descriptions
Network (Continued)	**Wired LAN** (Continued)	**Ethernet**	—	**Auto*** 100B-FD 100B-HD 10B-FD 10B-HD	Chooses the Ethernet link mode.
	WLAN	**TCP/IP**	**BOOT Method**	**Auto*** Static RARP BOOTP DHCP	Chooses the BOOT method that best suits your needs.
			IP Address	[000-255]. [000-255]. [000-255]. [000-255]	Enter the IP address.
			Subnet Mask	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Subnet mask.
			Gateway	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Gateway address.
			Node Name	BRWXXXXXXXXXXXX	Enter the Node name.
			WINS Config	**Auto*** Static	Chooses the WINS configuration mode.
			WINS Server	(Primary) 000.000.000.000 (Secondary) 000.000.000.000	Specifies the IP address of the primary or secondary server.
			DNS Server	(Primary) 000.000.000.000 (Secondary) 000.000.000.000	Specifies the IP address of the primary or secondary server.
	See *Network User's Guide on the CD-ROM*.				
	The factory settings are shown in Bold with an asterisk.				

Downloaded from ManualsPrinter.com Manuals

Level1	Level2	Level3	Level4	Options	Descriptions
Network (Continued)	**WLAN** (Continued)	**TCP/IP** (Continued)	**APIPA**	**On*** Off	Automatically allocates the IP address from the link-local address range.
		Setup Wizard	—	—	You can configure your print server.
		SES/WPS/AOSS	—	—	You can easily configure your wireless network settings using the one-button push method.
		WPS w/PIN Code	—	—	You can easily configure your wireless network settings using WPS with a PIN code.
		WLAN Status	**Status**	—	You can see the current wireless network status.
			Signal	—	You can see the current wireless network signal strength.
			SSID	—	You can see the current SSID.
			Comm. Mode	—	You can see the current Communication Mode.
	Network I/F	—	**Wired LAN*** WLAN	—	You can choose the network connection type.
	Factory Reset	—	—	Yes No	Restores all wired and wireless network settings to the factory default.
	See *Network User's Guide on the CD-ROM*.				
	The factory settings are shown in Bold with an asterisk.				

Downloaded from ManualsPrinter.com Manuals

Menu (Menu) (continued)

Level1	Level2	Level3	Options	Descriptions	Page
Print Reports	**Help List**	—	—	You can print these lists and reports.	23
	User Settings	—	—		
	Network Config	—	—		
Machine Info.	**Serial No.**	—	—	Lets you check the serial number of your machine.	84
Initial Setup	**Date&Time**	—	—	Puts the date and time on the LCD and in headings of faxes you send.	See *Quick Setup Guide*.
	Local Language		(Choose the language you want to use)	Allows you to change the LCD language for your country.	22
	The factory settings are shown in Bold with an asterisk.				

Copy (Default display)

Level1	Level2	Level3	Options	Descriptions	Page
Quality	—	—	Fast **Normal*** Best	Choose the Copy resolution for your type of document.	27
Enlarge/Reduce	**100%***	—	—	—	27
	Enlarge	—	142% A5→A4 186% 10x15cm→LTR 198% 10x15cm→A4	You can choose the enlargement or reduction ratio for your type of document.	27
	Reduce	—	47% A4→10x15cm 69% A4→A5 83% 93% A4→LTR 97% LTR→A4	You can choose the enlargement or reduction ratio for your type of document.	27
	Fit to Page	—	—	Your machine will adjust the size automatically to the paper size you set.	27
	Custom(25-400%)	—	—	You can choose the enlargement or reduction ratio for your type of document.	27
	The factory settings are shown in Bold with an asterisk.				

Downloaded from ManualsPrinter.com Manuals

Level1	Level2	Level3	Options	Descriptions	Page
Paper Type	—	—	**Plain Paper*** Inkjet Paper Brother BP71 Other Glossy Transparency	Choose the paper type that matches the paper in the tray.	30
Paper Size	—	—	**A4*** A5 10x15cm Letter Legal	Choose the paper size that matches the paper in the tray.	30
Brightness	—	—		Adjusts the brightness of copies.	29
Contrast	—	—		Adjusts the contrast of copies.	29
Page Layout	—	**Off(1 in 1)*** 2 in 1 (P) 2 in 1 (L) 4 in 1 (P) 4 in 1 (L) Poster(3x3)	—	You can make N in 1 or Poster copies.	28
Book Copy	On	—	—	Corrects dark borders and skew when copying from the scanner glass.	30
	On(Preview)	**(Skew Adjustment)**	—		
		(Shadow Revise)	—		
	Off*	—	—		
	The factory settings are shown in Bold with an asterisk.				

C

Downloaded from ManualsPrinter.com Manuals

Level1	Level2	Level3	Options	Descriptions	Page
Watermark Copy	**Watermark Copy**	—	On **Off*** (If you choose On, see the watermark copy settings in the following table.)	You can place a logo or text into your document as a Watermark.	31
	Current Setting	—	—		
	Exit	—	—		
Set New Default	—	—	Yes No	You can save your copy settings.	32
Factory Reset	—	—	Yes No	You can restore all settings to the factory settings.	32
	The factory settings are shown in Bold with an asterisk.				

Downloaded from ManualsPrinter.com Manuals

Watermark Copy Settings

Option1	Option2	Option3	Option4	Descriptions	Page
Template	—	**Text**	**CONFIDENTIAL***	Places a text into your document as a Watermark using a template.	31
			DRAFT		
			COPY		
		Position	A		
			B		
			C		
			D		
			E*		
			F		
			G		
			H		
			I		
			Pattern		
		Size	Small		
			Medium*		
			Large		
		Angle	-90°		
			-45°*		
			0°		
			45°		
			90°		
		Transparency	-2		
			-1		
			0*		
			+1		
			+2		
		Color	Red		
			Orange		
			Yellow		
			Blue		
			Green		
			Purple		
			Black*		
		Apply	—		

The factory settings are shown in Bold with an asterisk.

Downloaded from ManualsPrinter.com Manuals

Option1	Option2	Option3	Option4	Descriptions	Page
Media	(Select image from media)	**Position**	A B C D **E*** F G H I Pattern	Places a logo or text into your document as a Watermark using an image from removable media.	31
		Size	Small **Medium*** Large		
		Angle	-90° **-45°*** 0° 45° 90°		
		Transparency	-2 -1 **0*** +1 +2		
		Apply	—		
Scan	(Set page and press start)	**Transparency**	-2 -1 **0*** +1 +2	Places a logo or text into your document as a Watermark using a scanned image.	32
		Apply	—		
	The factory settings are shown in Bold with an asterisk.				

Downloaded from ManualsPrinter.com Manuals

PhotoCapture ( )

Level 1	Level 2	Level 3	Options	Descriptions	Page
View Photo(s)	—	—	See the print settings in the following table.	You can preview your photos on the LCD.	37
Print Index	—	Layout Format	**6 Images/Line***	You can print a thumbnail page.	38
			5 Images/Line		
		Paper Type	**Plain Paper***		
			Inkjet Paper		
			Brother BP71		
			Other Glossy		
		Paper Size	Letter		
			A4*		
Print Photos	—	—	See the print settings in the following table.	You can print an individual image.	38
Enhance Photos	Auto Correct	—		You can adjust your photos with these settings.	39
	Enhance Skin-Tone				
	Enhance Scenery				
	Remove Red-Eye				
	Monochrome				
	Sepia				
Search by Date	—	—		You can search your photos from date.	42
Print All Photos	—	—		You can print all photos in your media card or USB Flash memory drive.	43
Slide Show	—	—		The machine starts a Slide Show of your photos.	43
Trimming	—	—		You can trim your photo and print a part of the image.	44
	The factory settings are shown in Bold with an asterisk.				

C

Downloaded from ManualsPrinter.com Manuals

Print Settings

Option1	Option2	Option3	Option4	Descriptions	Page
Print Quality (Not available for DPOF printing)	Normal **Photo***	—	—	Choose the print quality.	46
Paper Type	Plain Paper Inkjet Paper Brother BP71 **Other Glossy***	—	—	Choose the paper type.	46
Paper Size	**10x15cm*** 13x18cm A4 Letter	(When A4 or Letter is chosen) 8 x 10cm 9 x 13cm 10 x 15cm 13 x 18cm 15 x 20cm **Max. Size***	—	Choose the paper and print size.	46
Brightness (Not available when Enhance Photos is chosen)		—	—	Adjusts the brightness.	47
Contrast (Not available when Enhance Photos is chosen)		—	—	Adjusts the contrast.	47
Color Enhance (Not available when Enhance Photos is chosen)	On **Off***	**White Balance**		Adjusts the hue of the white areas.	47
		Sharpness		Enhances the detail of the image.	
		Color Density		Adjusts the total amount of colour in the image.	

The factory settings are shown in Bold with an asterisk.

Downloaded from ManualsPrinter.com Manuals

Option1	Option2	Option3	Option4	Descriptions	Page
Cropping	**On***	—	—	Crops the image around the margin to fit the paper size or print size. Turn this feature off if you want to print whole images or prevent unwanted cropping.	48
	Off				
Borderless	**On***	—	—	Expands the printable area to fit the edges of the paper.	48
	Off				
Date Print (Not available for DPOF printing)	On	—	—	Prints the date on your photo.	48
	Off*				
Set New Default	—	—	Yes	You can save your print settings.	49
			No		
Factory Reset	—	—	Yes	You can restore all the settings to factory settings.	49
			No		
	The factory settings are shown in Bold with an asterisk.				

C

Downloaded from ManualsPrinter.com Manuals

Scan ( )

Level 1	Option 1	Option 2	Option 3	Descriptions	Page
Scan to E-mail	—	—	—	You can scan a monochrome or a colour document into your E-mail application.	See *Software User's Guide on the CD-ROM.*
Scan to Image	—	—	—	You can scan a colour picture into your graphics application.	
Scan to OCR	—	—	—	You can have your text document converted to an editable text file.	
Scan to File	—	—	—	You can scan a monochrome or a colour document into your computer.	
Scan to Media (When a memory card or USB Flash memory drive is inserted.)	**Quality**	—	**Color 150 dpi*** Color 300 dpi Color 600 dpi B/W 200x100 dpi B/W 200 dpi	You can choose the scan resolution and file format for your document.	50
	File Type	—	(If you chose Colour option in Quality setting) **PDF*** JPEG		
			(If you chose Mono option in Quality setting) **PDF*** TIFF		
	Set New Default	—	Yes No		
	Factory Reset	—	Yes No		

The factory settings are shown in Bold with an asterisk.

Downloaded from ManualsPrinter.com Manuals

D Specifications

General

Printer Type	Inkjet	
Print Method	Black:	Piezo with 94 × 1 nozzle
	Colour:	Piezo with 94 × 3 nozzles
Memory Capacity	(DCP-385C, DCP-383C and DCP-387C)	
	32 MB	
	(DCP-585CW)	
	40 MB	
LCD (liquid crystal display)	Wide 3.3 in. (83.8 mm) Color LCD	
Power Source	AC 220 to 240V 50/60Hz	
Power Consumption	(DCP-385C, DCP-383C and DCP-387C)	
	Off:	Average 0.5 W
	Sleep Mode:	Average 2.5 W
	Standby:	Average 4 W
	Operating:	Average 21 W
	(DCP-585CW)	
	Off:	Average 0.5 W
	Sleep Mode:	Average 4 W
	Standby:	Average 6 W
	Operating:	Average 23 W

Downloaded from ManualsPrinter.com Manuals

Dimensions

(DCP-385C, DCP-383C, DCP-387C and DCP-585CW)





Weight	(DCP-385C, DCP-383C and DCP-387C) 7.2 kg (DCP-585CW) 7.2 kg	
Noise	Operating:	LPAm = 50 dB or less [1]
Noise per ISO9296	Operating:	LWAd = 64.3 dB(A) (Mono) LWAd = 61.6 dB(A) (Colour) Office equipment with LWAd>63.0 dB(A) is not suitable for use in rooms where people do primarily intellectual work. Such equipment should be placed in separate rooms because of the noise emission.
Temperature	Operating:	10 - 35° C
	Best Print Quality:	20 - 33° C
Humidity	Operating:	20 - 80% (without condensation)
	Best Print Quality:	20 - 80% (without condensation)
Paper Tray	100 Sheets [80 g/m^2]	

[1] This depends on printing conditions.

Downloaded from ManualsPrinter.com Manuals

Print media

Paper Input	**Paper Tray** ■ Paper type: Plain paper, inkjet paper (coated paper), glossy paper [2], transparencies [1 2] and envelopes ■ Paper size: Letter, Legal, Executive, A4, A5, A6, JIS B5, envelopes (commercial No.10, DL, C5, Monarch, JE4), Photo 2L, Index card and Post card [3]. Width: 89 mm (3.5 in.) - 216 mm (8.5 in.) Length: 127 mm (5.0 in.) - 356 mm (14.0 in.) For more details, see *Paper weight, thickness and capacity* on page 19. ■ Maximum paper tray capacity: Approx. 100 sheets of 80 g/m^2 (20 lb) plain paper **Photo Paper Tray** ■ Paper type: Plain paper, inkjet paper (coated paper) and glossy paper [2] ■ Paper size: Photo 10×15cm and Photo L. Width: 89 mm (3.5 in.) - 101.6 mm (4.0 in.) Length: 127 mm (5.0 in.) - 152.4 mm (6.0 in.) ■ Maximum paper tray capacity: Approx. 20 sheets
Paper Output	Up to 50 sheets of A4 plain paper (face up print delivery to the paper tray) [2]

1 Use only transparencies recommended for inkjet printing.

2 For glossy paper or transparencies, we recommend removing printed pages from the paper tray immediately after they exit the machine to avoid smudging.

3 See *Paper type and size for each operation* on page 18.

Downloaded from ManualsPrinter.com Manuals

Copy

Colour/Monochrome	Yes/Yes
Document Size	Scanner Glass Width: Max. 215.9 mm Scanner Glass Length: Max. 297 mm Copy Width: Max. 210 mm
Multiple Copies	Stacks up to 99 pages
Enlarge/Reduce	25% to 400% (in increments of 1%)
Resolution	(Monochrome) ■ Scans up to 1200×1200 dpi ■ Prints up to 1200×1200 dpi (Colour) ■ Scans up to 600×1200 dpi ■ Prints up to 600×1200 dpi

Downloaded from ManualsPrinter.com Manuals

PhotoCapture Center™

Compatible Media [1]	CompactFlash® (Type I only) (Microdrive™ is not compatible) (Compact I/O cards such as Compact LAN card and Compact Modem card are not supported.) Memory Stick® Memory Stick Pro™ Memory Stick Duo™ with adapter Memory Stick Micro (M2) with adapter SD [2] SDHC [3] microSD with adapter miniSD™ with adapter xD-Picture Card™ [4] USB Flash memory drive [5]
Resolution	Up to 1200 × 2400 dpi
File Extension	DPOF, EXIF, DCF
(Media Format)	Photo Print: JPEG [6]
(Image Format)	Scan to Media: JPEG, PDF (Colour) TIFF, PDF (Black)
Number of Files	Up to 999 files (The folder inside memory cards or USB Flash memory drive is also counted)
Folder	File must be stored in the 4th folder level of the memory card or USB Flash memory drive.
Borderless	Letter, A4, Photo 10×15 cm, Photo 2L 13×18 cm [7]

1 Memory cards, adapters and USB Flash memory drive are not included.

2 16MB to 2GB

3 4GB to 8GB

4 xD-Picture Card™ Conventional Card from 16MB to 512MB
xD-Picture Card™ Type M from 256MB to 2GB
xD-Picture Card™ Type M+ 1GB and 2GB
xD-Picture Card™ Type H from 256MB to 2GB

5 USB 2.0 standard
USB Mass Storage standard from 16 MB to 8 GB
Support format: FAT12/FAT16/FAT32

6 Progressive JPEG format is not supported.

7 See *Paper type and size for each operation* on page 18.

Downloaded from ManualsPrinter.com Manuals

PictBridge

Compatibility	Supports the Camera & Imaging Products Association PictBridge standard CIPA DC-001. Visit http://www.cipa.jp/pictbridge for more information.
Interface	USB direct interface

Downloaded from ManualsPrinter.com Manuals

Scanner

Colour/Monochrome	Yes/Yes
TWAIN Compliant	Yes (Windows® 2000 Professional/XP/XP Professional x64 Edition/Windows Vista®) Mac OS® X 10.2.4 or greater
WIA Compliant	Yes (Windows® XP [1]/Windows Vista®)
Colour Depth	36 bit colour Processing (Input) 24 bit colour Processing (Output) (Actual Input: 30 bit colour/Actual Output: 24 bit colour)
Resolution	Up to 19200 × 19200 dpi (interpolated) [2] Up to 1200 × 2400 dpi (optical)
Scanning Speed	Colour: up to 4.83 sec. Monochrome: up to 3.44 sec. (A4 size at 100 × 100 dpi)
Document Size	Scanner Glass Width: Max. 215.9 mm Scanner Glass Length: Max. 297 mm
Scanning Width	Up to 210 mm
Greyscale	256 levels

1 Windows® XP in this User's Guide includes Windows® XP Home Edition, Windows® XP Professional, and Windows® XP Professional x64 Edition.

2 Maximum 1200 × 1200 dpi scanning when using the WIA Driver for Windows® XP and Windows Vista® (resolution up to 19200 × 19200 dpi can be chosen by using the Brother scanner utility)

D

Downloaded from ManualsPrinter.com Manuals

Printer

Printer Driver	Windows® 2000 Professional/XP/XP Professional x64 Edition/Windows Vista® driver supporting Brother Native Compression mode
	Mac OS® X 10.2.4 or greater: Brother Ink Driver
Resolution	Up to 1200 × 6000 dpi
	1200 × 2400 dpi
	1200 × 1200 dpi
	600 × 1200 dpi
	600 × 600 dpi
	600 × 300 dpi
	600 × 150 dpi (Colour)
	450 × 150 dpi (Monochrome)
Print Speed	(DCP-385C, DCP-383C, DCP-387C)
	Black: Up to 30 pages/minute [1]
	Color: Up to 25 pages/minute [1]
	(DCP-585CW)
	Black: Up to 33 pages/minute [1]
	Color: Up to 27 pages/minute [1]
Printing Width	204 mm (210 mm) [2]
Borderless	Letter, A4, A6, Photo 10×15cm, Index Card, Photo L, Photo 2L, Post Card [3]

1 Based on Brother standard pattern.
A4 size in draft mode.

2 When you set the Borderless feature to On.

3 See *Paper type and size for each operation* on page 18.

Downloaded from ManualsPrinter.com Manuals

Interfaces

USB [1] [2]	A USB 2.0 interface cable that is no longer than 2.0 m.
LAN cable [3] **(DCP-585CW only)**	Ethernet UTP cable category 5 or greater.
Wireless LAN (DCP-585CW only)	Your machine supports IEEE 802.11b/g wireless communication with your wireless LAN using Infrastructure mode or a wireless Peer-to-Peer connection in Ad-hoc Mode.

1 (DCP-585CW)
Your machine has a Hi-speed USB 2.0 interface. The machine can also be connected to a computer that has a USB 1.1 interface.
(DCP-385C/383C/387C)
Your machine has a full-speed USB 2.0 interface. This interface is compatible with Hi-Speed USB 2.0; however, the maximum data transfer rate will be 12 Mbits/s. The machine can also be connected to a computer that has a USB 1.1 interface.

2 Third party USB ports are not supported for Macintosh®.

3 See the *Network User's Guide* on the CD-ROM for detailed network specification.

Downloaded from ManualsPrinter.com Manuals

Computer requirements

SUPPORTED OPERATING SYSTEMS AND SOFTWARE FUNCTIONS								
Computer Platform & Operating System Version		**Supported PC Software Functions**	**PC Interface**	**Processor Minimum Speed**	**Minimum RAM**	**Recommended RAM**	**Hard Disk Space to install**	
							For Drivers	**For Applications**
Windows® Operating System [1]	2000 Professional [4]	Printing, Removable Disk	USB, 10/100 BaseTx (Ethernet), Wireless 802.11b/g	Intel® Pentium® II or equivalent	64 MB	256 MB	110 MB	340 MB
	XP Home [2 4] XP Professional [2 4]				128 MB		110 MB	340 MB
	XP Professional x64 Edition [2]			64-bit (Intel®64 or AMD64) supported CPU	256 MB	512 MB	110 MB	340 MB
	Windows Vista® [2]			Intel® Pentium® 4 or equivalent 64-bit (Intel®64 or AMD64) supported CPU	512 MB	1 GB	600 MB	530 MB
Macintosh® Operating System [5]	Mac OS® X 10.2.4 - 10.4.3	Printing, Removable Disk	USB [3], 10/100 BaseTx (Ethernet), Wireless 802.11b/g	PowerPC G4/G5 PowerPC G3 350MHz	128 MB	256 MB	80 MB	400 MB
	Mac OS® X 10.4.4 or greater	Printing, Removable Disk	USB [3], 10/100 BaseTx (Ethernet), Wireless 802.11b/g	PowerPC G4/G5 Intel® Core™ Processor	512 MB	1 GB		

Conditions:

1 Microsoft® Internet Explorer 5.5 or greater.

2 For WIA, 1200 x 1200 resolution. Brother Scanner Utility enables to enhance up to 19200 x 19200 dpi.

3 Third party USB ports are not supported.

4 PaperPort™ 11SE supports Microsoft® SP4 or higher for Windows® 2000 and SP2 or higher for XP.

5 Presto!® PageManager® on the CD-ROM supports Mac OS® X 10.3.9 or higher. For Mac OS® X 10.2.4-10.3.8 Presto!® PageManager® is available as a download from the Brother Solutions Center.

For the latest driver updates, visit http://solutions.brother.com/

All trademarks, brand and product names are property of their respective companies.

Downloaded from ManualsPrinter.com Manuals

Consumable items

Ink	The machine uses individual Black, Yellow, Cyan and Magenta ink cartridges that are separate from the print head assembly.
Service Life of Ink Cartridge	The first time you install a set of ink cartridges the machine will use an amount of ink to fill the ink delivery tubes for high quality printouts. This process will only happen once. With all following ink cartridges you can print the specified number of pages. The cartridges provided with your machine have a lower yield than standard cartridges (65%).

Replacement Consumables

Ink cartridge

Black	Yellow	Cyan	Magenta
LC1100BK	LC1100Y	LC1100C	LC1100M
			

Black - Approximately 450 pages [1]

Yellow, Cyan and Magenta - Approximately 325 pages [1]

For more information about the replacement consumables, visit us at http://www.brother.com/pageyield.

[1] Approx. cartridge yield is declared in accordance with ISO/IEC 24711.

What is Innobella™?

Innobella™ is a range of genuine consumables offered by Brother. The name "Innobella™" derives from the words "Innovation" and "Bella" (meaning "Beautiful" in Italian) and is a representation of the "innovative" technology providing you with "beautiful" and "long lasting" print results.

When you print photo images, Brother recommends Innobella™ glossy photo paper (BP71 series) for high quality. Brilliant prints are made easier with Innobella™ Ink and paper.

Downloaded from ManualsPrinter.com Manuals

Network (LAN) (DCP-585CW only)

LAN	You can connect your machine to a network for Network Printing, Network Scanning and Remote Setup [1] (Windows® only). Also included is Brother BRAdmin Light [2] Network Management software.	
Support for	Windows® 2000 Professional/XP/XP Professional x64 Edition/Windows Vista®	
	Mac OS® X 10.2.4 or greater	
	Ethernet 10/100 BASE-TX Auto Negotiation (Wired LAN)	
	IEEE 802.11 b/g (Wireless LAN)	
Protocols	TCP/IP for IPv4:	ARP, RARP, BOOTP, DHCP, APIPA (Auto IP), NetBIOS/WINS, LPR/LPD, Custom Raw Port/Port9100, DNS Resolver, mDNS, FTP Server, TELNET, SNMPv1, TFTP, Scanner Port, LLTD responder, Web Services
Network Security	SSID/ESSID, 128 (104) / 64 (40) bit WEP, WPA/WPA2-PSK (TKIP/AES)	
Setup Support Utility	**SecureEasySetup™**	Yes (simple setup with your SecureEasySetup™-capable access point/router)
	AOSS™	Yes (simple setup with your AOSS™-capable access point/router)
	WPS	Yes (simple setup with your Wi-Fi Protected Setup™-capable access point/router)

1 See the Computer Requirements chart on page 110.

2 If you require more advanced printer management, use the latest Brother BRAdmin Professional utility version that is available as a download from http://solutions.brother.com.

Downloaded from ManualsPrinter.com Manuals

Wireless one-push configuration

If your wireless access point supports either SecureEasySetup™, Wi-Fi Protected Setup™ (PBC [1]) or AOSS™, you can configure the machine easily without a computer. By pushing a button on the wireless LAN router / access point and the machine, you can set up the wireless network and security settings. See the users guide for your wireless LAN router / access point for instructions on how to access one-push mode.

[1] Push Button Configuration

Note

Routers or access points that support SecureEasySetup™, Wi-Fi Protected Setup™ or AOSS™ have the symbols shown below.

D

Downloaded from ManualsPrinter.com Manuals

E Glossary

This is a comprehensive list of features and terms that appear in Brother manuals. Availability of these features depends on the model you purchased.

Brightness

Changing the Brightness makes the whole image lighter or darker.

Contrast

Setting to compensate for dark or light documents, by making copies of dark documents lighter and light documents darker.

Colour Enhancement

Adjusts the colour in the image for better print quality by improving sharpness, white balance and colour density.

Greyscale

The shades of grey available for copying and scanning.

Help list

A printout of the complete Menu table that you can use to program your machine when you do not have the User's Guide with you.

Innobella™

Innobella™ is a range of genuine consumables offered by Brother.For best quality results Brother recommends Innobella™ Ink and Paper.

LCD (liquid crystal display)

The display screen on the machine that shows interactive messages during On-Screen Programming.

Menu mode

Programming mode for changing your machine's settings.

OCR (optical character recognition)

The bundled ScanSoft™ PaperPort™ 11SE with OCR or Presto!® PageManager® software application converts an image of text to text you can edit.

PhotoCapture Center™

Allows you to print digital photos from your digital camera at high resolution for photo quality printing.

PictBridge

Allows you to print photos directly from your digital camera at high resolution for photo quality printing.

Scanning

The process of sending an electronic image of a paper document into your computer.

Scan to Media

You can scan a monochrome or colour document into a memory card or USB Flash memory drive. Monochrome images can be in TIFF or PDF file format and colour images may be in PDF or JPEG file format.

Temporary settings

You can choose certain options for each copy without changing the default settings.

User Settings

A printed report that shows the current settings of the machine.

Downloaded from ManualsPrinter.com Manuals

F Index

A

Apple® Macintosh®
See Software User's Guide on the CD-ROM. .....

C

Cleaning
paper pick-up roller 81
print head 82
printer platen 81
scanner 80
Consumable items 111
Control panel overview 6
ControlCenter
See Software User's Guide on the CD-ROM. .....
Copy
book 30
brightness 29
contrast 29
enlarge/reduce 27
multiple 26
page layout (N in 1, poster) 28
paper size 30
paper type 30
quality 27
Return to default 32
set new default 32
single 26
using scanner glass 20
watermark 31
using a Flash memory drive 31
using a paper document 32
using a template data 31
using media cards 31

D

Direct printing
from a non-PictBridge camera 53
from a PictBridge camera 52
Document
loading 20

E

Envelopes 11, 12, 13, 18
Error messages on LCD 72
B&W Print Only 72
Cannot Print 72
Ink Low 73
No Cartridge 73
No Paper Fed 74
Out of Memory 74
Unable to Clean 74
Unable to Init. 74
Unable to Print 74
Unable to Scan 74

G

Greyscale 107

H

Help
LCD messages 87
using Menu keys 87
Menu Table 87, 88

I

Ink cartridges
checking ink volume 84
ink dot Counter 77
replacing 77
Ink key 7
Innobella™ 111

J

Jams
paper 75

L

LCD (liquid crystal display) 87
Brightness 23
Contrast 22
Dim Timer 23
Help List 23
Language 22

Downloaded from ManualsPrinter.com Manuals

M

Macintosh®
See Software User's Guide on the CD-ROM. .....
Maintenance, routine
replacing ink cartridges 77
Menu Table 87
Mode, entering
PhotoCapture 7
Scan 7

N

Network
Printing
See Network User's Guide on the CD-ROM. .....
Scanning
See Software User's Guide on the CD-ROM. .....
Number of Copies key 6

O

On/Off key 6
Out of Memory message 74

P

Paper 16, 103
capacity 19
loading 9, 11, 13
printable area 15
size 18, 21
type 18, 21
PaperPort™ 11SE with OCR
See Software User's Guide on the CD-ROM and Help in the PaperPort™ 11SE application to access How-to-Guides. .....
Photo Paper Tray 13
PhotoCapture Center™
Adding Effect 39
Borderless 48
CompactFlash® 34
Cropping 48
Date Print 48
DPOF printing 44
from PC
See Software User's Guide on the CD-ROM. .....
Memory Stick Pro™ 34
Memory Stick® 34
Photo Effects
Auto Correct 39
Enhance Scenery 40
Enhance Skin-Tone 40
Monochrome 41
Remove Red-Eye 41
Sepia 42
Preview photos 37
Print settings
Brightness 47
Colour enhancement 47
Contrast 47
Paper type & size 46
Quality 45, 46
Return to factory setting 49
Set new default 49
Printing
all photos 43
index 38
photos 38
Scan to memory card 49
Scan to USB flash memory 49
SD 34
SDHC 34
Search from Date 42
Slide-Show 43
specifications 105
Trimming 44
xD-Picture Card™ 34
PictBridge
DPOF Printing 53
Presto!® PageManager®
See Help in Presto!® PageManager® application .....
Print
area 15
difficulties 67
drivers 108
improving quality 82
on small paper 14
paper jams 75
reports 23
resolution 108
specifications 108
Programming your machine 87

Downloaded from ManualsPrinter.com Manuals

R

Reducing copies 27
Reports
  Help List 23
  how to print 23
  User Settings 23
Resolution
  copy 104
  print 108
  scan 107

S

Safety Instructions 62
Scannable area 20
Scanner glass
  cleaning 80
  using 20
Scanning
  See Software User's Guide on the CD-ROM. .....
Serial Number
  how to find..... See inside front cover
Shipping the machine 84
Sleep time 22

T

Transparencies 16, 19, 103
Troubleshooting 67
  checking ink volume 84
  error messages on LCD 72
  if you are having difficulty
    copying 69
    Network 71
    PhotoCapture Center™ 70
    printing 67
    scanning 69
    software 70
  paper jam 75
  print quality 82

W

Windows®
  See Software User's Guide on the CD-ROM. .....

F

Downloaded from ManualsPrinter.com Manuals

Visit us on the World Wide Web
http://www.brother.com

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.

Downloaded from ManualsPrinter.com Manuals